

# **TELEFUNKEN**

## **INSTRUKCJA OBSŁUGI OPERATING INSTRUCTIONS**

### **24HG6011**

**HDMI™**  
HIGH-DEFINITION MULTIMEDIA INTERFACE



Socia fono-óci

Información documental en la naturaleza

- | Informacje dotyczące bezpieczeństwa  |   |
|--|---|
| <br><b>OSTRZEŻENIE</b><br>RYSKO ZARYSOWANIA PRĄDEM<br>NIE OTWIERAĆ   | <b>OSTRZEŻENIE:</b> Aby zanieść ryzyko porażenia prądem, zawsze odłącz telewizor od gniazda sieciowego, kiedy nie jest połączony z obudową. Kiedy telewizor nie jest połączony z obudową, należy go zawsze naprawiać w kwalifikowanym personelu.  |
| <br><b>OSTRZEŻENIE:</b> W przypadku aktywnego wstrząsku, gromowych burz, biegów silników, itp. może dojść do uderzenia w kontakty. Występuje ryzyko porażenia prądem. Wysuń zasilającą urządzenie silnie do końca, aby zatrzymać uderzenie. Po każdym uderzeniu należy zawsze odłączyć telewizor od gniazda sieciowego, kiedy nie jest połączony z obudową. Kiedy telewizor nie jest połączony z obudową, należy go zawsze naprawiać w kwalifikowanym personelu. | <b>WAŻNE - Proszę przeczytać całą instrukcję przed instalacją i uzytkowaniem</b>  |
| <br><b>OSTRZEŻENIE:</b> Nigdy nie pozwalaj osobom (rownież dzieciom) z ręcznymi, sensorycznymi lub umysłowymi upośledzeniami lub brakiem doświadczenie i/ lub wiedzy na korzystanie z urządzenia. Dla bezpieczeństwa i dla uzyskania pełnego bezpieczeństwa elektrycznego bez nadzoru.   | <b>Klasa I. Wyposażone w zabezpieczenia na produkcie</b><br>Następujące symbole zostały użyte na produkcie, zebu zaznaczają ograniczenia, środki ostrożności i zasadę bezpieczeństwa. Każde z wyjaśnzeń należy zasadą uwagi, kiedy produkt posiada od powietrza oznaczenie: Proszę zwrócić uwagę na te informacje wzejściowej bezpieczeństwa. |
| <br><b>OSTRZEŻENIE:</b> Nigdy nie pozwalaj osobom (rownież dzieciom) z ręcznymi, sensorycznymi lub umysłowymi upośledzeniami lub brakiem doświadczenia i/ lub wiedzy na korzystanie z urządzenia. Dla bezpieczeństwa i dla uzyskania pełnego bezpieczeństwa elektrycznego bez nadzoru.   | <b>Klasa II. Wyposażone w zabezpieczenia na produkcie</b><br>Urządzenie to jest tak zaprojektowane, ze nie wymaga zabezpieczenia w postaci izolowania w gniazdku.   |
| <br><b>OSTRZEŻENIE:</b> Nigdy nie pozwalaj osobom (rownież dzieciom) z ręcznymi, sensorycznymi lub umysłowymi upośledzeniami lub brakiem doświadczenia i/ lub wiedzy na korzystanie z urządzenia. Dla bezpieczeństwa i dla uzyskania pełnego bezpieczeństwa elektrycznego bez nadzoru.   | <b>Klasa III. Wyposażone z funkcjonalnym usterzeniem</b><br>Urządzenie to jest tak zaprojektowane, ze nie wymaga zabezpieczenia w postaci izolowania w gniazdku, uzupełnione jest użyciem tylko dla celów funkcjonalnych.   |
| <br><b>Ochronne podłączenie z uziemieniem:</b>   | <b>Oznaczenie przyjęte jest przeznaczone do</b>   |

	<b>OSTRZEŻENIE</b>	RYZNO PORĘŻNIKI DOZARZENIA NIE OTWIERAĆ
	OSTRZEŻENIE: ABB ZNANIELECZ CZYŻKO DOZARZENIA PRĄDEM, NIE ZDZIĘMU OBUDOWY LUB TYŁU. W ŚRODKU NIE MA ZADYNY CZĘŚCI, KTEREJ BYŁA WYKRAWIĆ, WYKALIBROWAĆ PESELZONI LOWI	W przypadku ekstremalnych warunków pogodowych (deszcz, wykawka) ułagaj okresowe miedzywymiarowe (wyłączyc) wysyłki zasilań i urządzanie skutego do odłączenia TV od zasilania, powinno więc być aktywo podejmowane. Jeżeli telewizor nie jest odłączony od sieci elektrycznej, uruchamiać wtedy, gdy nasil pobjawa się w dżazie sytuacji (uruchamiać specjalne ustroje, wykrywacze)
	Informacje dotyczące bezpieczeństwa..... 2	2
	Przyczyniać się do zatrudnienia na produkcję..... 2	2
	Informacje ekologiczne..... 4	4
	Uniecue..... 4	4
	Alejonezone akcesoria..... 4	4
	Informacje w trybie oczekiwania..... 4	4
	Rzyckiski kontroli obrazu TV..... 5	5
	Kładanie baleci do pilota..... 6	6
	Odłączanie zasilania..... 6	6
	Odłączanie anteny..... 6	6
	Informacje dotyczące licencji pryfikacji..... 7	7
	loilo..... 8	8

<b>WAŻNE - Proszę przeczytać i całą instrukcję przed instalacją i użytkowaniem</b>	<b>A</b> OSTRZEŻENIE: Niżdy nie pozwalaj osobomom (również dzieciom) z fizycznymi, sensorycznymi lub umysłowymi upośledzeniami lub bakiem do wszczęcia i/lub wiedzy na korzystanie z urządzeń elektrycznych bez nadzoru.
Instalowanie mediów poprzez wejście USB	10
Instalowanie mediów poprzez przejściaki mediów .....	11
EC .....	11
Widownia menu TV	12
Widownia ogólna TV .....	16
Wykawocąć .....	16
Wykorzystanie z isty kanałów .....	16
Wykonanie ustawień kontroli rodzinnej .....	16
Zmiana elektroniczny przewodnik po programach (EPG) .....	16
Słuski telelektorskie .....	17
Konfiguracja oprogramowania .....	17
Czyszczanie problemów i wskaźników .....	17
Przypisywanie sygnałów AV i HDMI .....	18
Obsługiwane formaty plików dla trybu USB .....	19

- Dla celów wentylacji należy pozostać co najmniej 5 cm od ściany wokół telewizora.
- Nie powinno się zakończyć wentylacji poprzez zakrycie obuory wentylacyjnych przedmiotami takimi, jak czaszki, obrusy, zasłony itp.

**Klasa II, Wyposażenie** Urządzenie to jest tak zaprojektowane, że nie wymaga zabezpieczenia w pozycji użyczenia w gniazdce.

**Uziemienie:** Urządzenie to jest tak zaprojektowane, że nie wymaga w założeniu w postaci uziemienia w gniazdce, uziemienie jest używane tylko dla celów funkcjonalnych.

**Ochronne podłączenie z uziemieniem:** Oznaczone przyciągięcia jest przeznaczone do

podłączenia przewodu uziemiającego, ochronego w okablowieniu zasilania.

#### Niebezpieczne przyjazne pod napięciem:

Zaznaczony przyjazny jest niebezpieczne w normalnych warunkach użytkowania.



#### Urządzenie laserowe

**Klasa 1 - Urządzenie laserowe**  
wyposażone jest w laser wykazujący klasę 1, bezpieczny w przypadku używania przez różnych użytkowników.

używania.

#### OSTRZEŻENIE

Nie polikal baterii, rzyku poparzeń chemicznych. Produkt lub dołączone do niego akcesoria mogą zawierać baterię, pastylkę. Jeśli zostanie ona połknęta, może spowodować groźne wewnętrzne porażenia już w czasie 2 godzin może doprowadzić do śmierci. Trzymaj nowe i zużyte baterie z dala od dzieci. Jesli przeźrogi na baterię nie da się bezpieczeństwa zamknąć, przestan korzystać z urządzenia i trzymaj go z dala od dzieci. Jesli podjeżdżasz, że bateria mogła zostać pochłonięta lub umieszczona w plejtkach części ciała, natychmiast udaj się do lekarza.

#### OSTRZEŻENIE

Telewizor może spaść, powodując poważne obrażenia ciała lub śmierć. Wiele obrażeń, szczególnie w warunkach użytkowania zastępowało następującymi, prostymi środkami ostrożności:

- ZAWSZE używaj szalek lub stojaków poleceanych przez producenta telewizora.
- ZAWSZE używaj mebli mających bezpieczne uchwytowanie telewizorów.
- ZAWSZE upewnij się, że telewizor nie wystaje poza krawędź mebla, na którym stoi.
- ZAWSZE informuj dzieci o niebezpieczeństwach związanych z użyciem mebli, aby dostosować je do przyczek na telewizorze.
- Zawsze prowadź kable przedwoju podcięzione do telewizora tak, aby nie można było się nie potknąć, poślizgnąć i tak inni chwycić.
- NIGDY nie stawiaj telewizora na niestabilnym podkolu.
- NIGDY nie umieszczaj telewizora na wysokich meblach (np. półki na książki i szafki) bez przyciągania załatwionego sznurkiem bez do dopasowania założenia.
- NIGDY nie umieszczaj telewizora na siedelnicach i innym materiałach zasadzających się pomiędzy telewizorem, a meblami na którym stoi.
- NIGDY nie umieszczaj przedmiotów, które mogłyby skusić dzieci do wspinania się na zabawki i płyty, na telewizorze lub meblach, na których telewizor jest umieszczony.
- Urządzenie nadaje się tylko do montażu na wysokości  $\leq 2$  m. Jeśli obecny telewizor ma być przeniesiony powinny być zachowane te same polaryzacje zasady co do jego ustawiania.

#### OSTRZEŻENIA DOTYCZĄCE MONTAŻU NAŚCIEMNIEGO

- Przed przystąpieniem do montażu telewizora na ściance zapoznaj się z instrukcją.
- Zestaw do montażu naściemnego jest opcjonalny. Można go nabycu lokalnego dystrybutora, jeśli nie znajdzisz się w zestawie z telewizorem.
- Nie nalaż instalować telewizora na suficie lub na pochyłej ścianie.
- Montaż z określonych grubością innych akcesoriów.
- Dokrć tątaby mocujące mocno tak, aby zabezpieczyć telewizor przed upadekiem. Nie należy nadmiernie dokręcać grub.

#### OSTRZEŻENIE

- Urządzenie podlega za prawidłowe użyczenia budynku poprzez ZASILANIA lub inne urządzenie wyposażone w podcięcie użyczenia oraz systemu dostarczania TV porządku kabeli gospodarczych.
- Automatyczna wyłączenie po maksymum 60 minutach.
- Wyłącznik czasowy
- Blokada klawiszy
- Automatyczne wyłączenie dźwięku, jeżeli nie jest odbierana żadna transmisja.

#### Informacje ekologiczne

Televizor ten jest konstruowany tak, aby być przyjazny dla środowiska. Aby zmniejszyć zużycie energii, można wykonać krok:

- Ustawisz ustawisko oszczędzanie energii na minimalne średnie, maksymalne lub auto, ty odrzucisz zminiaturyzowany zapis energii. Jeśli chcesz, możesz ustawić c podświetlenie na określone wartości ustawniona jako osobista, ustawić podświetlenie (umieszczone w ustawieniach oszczędzania energii) reżimu, korzystając z funkcji lewej i prawej strony.

Ustaw jako wyłączone, aby wyłączyć.

**Uwaga:** Dostępnego opcje oszczędzania energii mogą różnić się w zależności od wybranego typu ustawienia System-Obraz.

Opcje oszczędzania energii mogą odnosić się do: System-Obraz, Twój obraz, unikalny, no, zielone światło, ustawienia obrazu, itp. Wtedy nie będzie możliwe odczytanie informacji o ustawieniach oszczędzania energii.

Jesli zostanie naciśnięty przycisk klawiszkowy lewo i prawo na płyce, Ustaw jako wyłączone, aby wyłączyć.

**Uwaga:** Dostępnego opcje oszczędzania energii mogą różnić się w zależności od wybranego typu ustawienia System-Obraz.

Opcje oszczędzania energii mogą odnosić się do: System-Obraz, Twój obraz, unikalny, no, zielone światło, ustawienia obrazu, itp. Wtedy nie będzie możliwe odczytanie informacji o ustawieniach oszczędzania energii.

Jesli telewizor nie będzie obsługiwanym przez pewien czas, przełączy się on w tryb oczekiwania. Gdy nastąpienie wiązisz TV, zostanie wyświetlona

#### OSTRZEŻENIE

- Przed przystąpieniem do montażu telewizora na ściance zapoznaj się z instrukcją.
- Zestaw do montażu naściemnego jest opcjonalny. Można go nabycu lokalnego dystrybutora, jeśli nie znajdzisz się w zestawie z telewizorem.
- Nie nalaż instalować telewizora na suficie lub na pochyłej ścianie.
- Montaż z określonych grubością innych akcesoriów.
- Dokrć tątaby mocujące mocno tak, aby zabezpieczyć telewizor przed upadekiem. Nie należy nadmiernie dokręcać grub.

#### Funkcje

- Telewizor kolorowy obsługiwany za pomocą pilota.
- W pełni zintegrowana TV cyfrowa nadawana/kablowa satelitarna (DVB-T/T2/C)
- Wejście HDMI do podcięcia innego urządzenia w gniazdzie HDMI
- Wejście USB
- System menu OSD
- System dźwięku stereofonicznego
- Telekst
- Podcięcie skuchawek
- Automatyczny System Programowania
- Strojenie reżimu
- Wyłączenie po maksymum 60 minutach
- Wyłączenie po godzinach.
- Wyłącznik czasowy
- Blokada klawiszy
- Automatyczne wyłączenie dźwięku, jeżeli nie jest odbierana żadna transmisja.

#### Informacje w trybie oczekiwania


Jesli TV nie odbierze żadnego sygnału (np.: z anteny lub z gniazda HDMI) przez 3 minuty, przełączy się w tryb oczekiwania. Gdy nastąpienie wiązisz TV, zostanie wyświetlona następująca wiadomość: "TV automatycznie przełączy się w tryb oczekiwania z powodu braku sygnału przez okres czasu".

Wciśnij OK, aby kontynuować.

Jesli telewizor nie będzie obsługiwanym przez pewien czas, przełączy się on w tryb oczekiwania. Gdy nastąpienie wiązisz TV, zostanie wyświetlona

następujaca wiadomość: "TV automatycznie przełącz się w tryb oczekiwania z powodu niekorzystania i niego przez dłuższy okres czasu." Wcisnąć OK, aby kontynuować.

#### Prysznic kontrolne i obsługiwane TV



**Uwaga:** Umiejscowienie przycisku sterowania może się różnić w zależności od modelu.

Television jest wyposażony w jeden przycisk sterowania. Przycisk sterowania umożliwia obsługę głosowej karty z funkcją usprawnienia telewizora.

#### Obsługa telewizora za pomocą przycisku sterowania

- Naciśnij przycisk sterowania, aby wyświetlić menu. Użyj przycisków sterunkowych i przycisku OK, aby nawigować i ustawić. Naciśnij przycisk Wyjdź/Powrót lub Menu, aby wyjść z ekranu menu.
- Uwaga:** Nie można wyjść z menu głównego OSD przy użyciu przycisku sterowania.

#### Obsługa za pomocą przycisku pomocnika pilota

Naciśnij przycisk Menu na pilocie, aby wyświetlić główne menu. Użyj przycisków sterunkowych i przycisku OK, aby nawigować i ustawić. Naciśnij przycisk Wyjdź/Powrót lub Menu, aby wyjść z ekranu menu.

#### Wybór wejścia

Po podłączeniu systemów zewnętrznych do telewizora, można go przełączyć na inną źródła wejściowe. Naciśnij przycisk Źródła na pilocie, aby wybrać inną źródła.

#### Zmiana kanałów i głośności

Użyj przycisków Program+ i Głośność+ na pilocie, aby zmienić kanały i dopasować głośność. Naciśnij przycisk Źródła na pilocie, aby wybrać inną źródła.

#### Resetowanie i włączenie za pomocą przycisku trybu gotowości

Naciśnij przycisk trybu gotowości, aby wywołać dodatkowe czynności związane z tym przyciskiem. Dostępne będą opcje Resetowanie (uruchom ponownie). Tryb gotowości (Normalny tryb gotowości) i Wyłącz zasilanie (wyムzaczony tryb gotowości). Profesjaliści jedzą i naciśnij OK, aby wykonać wybrane czynności. Jeśli wystąpi problem, który uniemożliwi prawidłowe przełączanie telewizora w trybie sterowania, użyj przycisku Wyłącz zasilanie, aby wymusić przełączenie się telewizora w tryb gotowości.

Jeśli telewizor przełączy się na polecenia oraz nie można wyświetlić menu czynności, telewizor zostanie zmuszony, do ponownego uruchomienia, aby przysiąk przed każdym użyciem. Spowoduje to zakończenie procesu.

Włączenie. Następnie naciśnij przycisk, aby zwiększyć lub zmniejszyć poziom głośności.

**Aby zmienić kanal:** Naciśnij przycisk sterowania, aby wyświetlić menu opcji funkcji, a następnie naciśnij przycisk sterowania raz, aby podstawić opcję **Program + lub Program -**. Naciśnij przycisk sterowania, aby zmienić kanal, aby aktywować wybraną opcję. Kolor ikony opcji zmieni się po jej włączaniu. Następnie naciśnij przycisk, aby zmienić, aby przejść do następnej lub poprzedniej kanału. Następnie naciśnij przycisk sterowania.

#### Wkładanie baterii do pilota

Najpierw wykręć śrubkę zabezpieczającą przegrodę na baterię, znajdującą się z tyłu pilota. Delikatnie podnieś pokrywę. Włożyć dwie baterie **AAA**. Upewnij się, że 1 – sa stworzone we właściwej stronie. Nie mieszaj stary i nowy baterii. Baterie wymieniamy razem na inne tego samego lub równoważnego typu. Zamknij klapkę w powrotnym. Następnie, przykręć śrubkę z powrotem.



**Uwaga:** Umiejscowienie przycisku sterowania może się różnić w zależności od modelu.

Television jest wyposażony w jeden przycisk sterowania. Przycisk sterowania umożliwia obsługę głosowej karty z funkcją usprawnienia telewizora.

#### Obsługa telewizora za pomocą przycisku sterowania

- Naciśnij przycisk sterowania, aby wyświetlić menu funkcji. Użyj przycisków sterunkowych i przycisku funkcji, aby wybrać funkcję, której majątek wyrażają ostatnio aktywowaną opcję. Naciśnij i przymierzaj przycisk, aby włączyć. Kolor ikony opcji zmieni się po jej włączaniu.
- Aby zamknąć menu opcji funkcji, naciśnij przycisk sterowania przez około 5 sekund. Menu opcji funkcji zminkie.

**Aby włączyć telewizor:** Naciśnij przycisk sterowania, aby wyświetlić menu opcji funkcji, zaznaczenie podświetlona opcja **Gotowość**. Naciśnij przycisk sterowania, aby zmienić menu opcji funkcji, zaznaczenie przycisku raz, aby włączyć, aby uzupełnić ikonę. Kolor ikony opcji zmieni się po jej włączaniu. Naciśnij przycisk ponownie, aby wyłączyć telewizor.

#### Aby włączyć telewizor:

Naciśnij przycisk sterowania, a telewizor sie włączy.

#### Aby zmienić głośność:

Naciśnij przycisk sterujące, aby wyświetlić menu czynności, telewizor zostanie zmuszony, do ponownego uruchomienia, aby przysiąk raz, aby podstawić opcję **Głośność + lub Głosność -**. Naciśnij przycisk sterowania, aby zmienić głośność. Kolor ikony opcji zmieni się po jej

#### Podłączenie anteny

Podłącz antenę lub telewizor kablowy do gniazda WE/SCIA ANTENOWEGO (ANT), znajdującego się z tyłu telewizora.



ANT

#### Informacje dotyczące licencji

Terminy HDMI, HDMI High Definition Multimedia Interface, HDMI sa znakami towarzyszącymi lub zarejestrowanymi znakami towarzyszącymi HDMI Licensing Administrator, Inc.



High Definition Multimedia Interface

Wyprodukowane na licencji Dolby Laboratories. Dolby, Dolby Audio, i podwójne-D są znakami towarzyszącymi Dolby Laboratories, Licensing Corporation.

Logo CI Plus jest znakiem towarzyszącym CI Plus LLP. Unia Europejska Logo PIP pod symboliem fabryki/opracowania ze zbiorem ołówka.

(Tytuł kraju UE)

Sprzętu noszącego ten symbol nie wolno wyizzare za zwykłymi odpadami komunalnymi.


Aby położyć się tych wyrobów, należy poszukać przeznaczonych do tego celu obiektów i systemów. Unia Europejska Logo PIP pod symboliem fabryki/opracowania ze zbiorem ołówka.



Baterie:



Symbol



wykorzystywanych

zbyt


długo

zbyt

długo

Podłączenie zasilania


Ważne: Telefon jest zaprojektowany do korzystania z prądu zmienionego 220-240V, 50 Hz. Po rozpakowaniu, należy pozwolić urządzeniu osiągnąć temperaturę otoczenia przed podłączeniem go do prądu.



Podłącz jeden koniec (dwutorcową wtyczkę) do właściwego odłączanego przewodu zasilającego do wejścia przewodu zasilającego z tyłu telewizora, co pokazano powyżej. Następnie podłącz drugi koniec przewodu zasilającego do gniazdka.

**Uwaga:** Wielkość przewodu zasilającego może się różnić w zależności od modelu.

Transmisja telewizyjne	PAL B/G D/K K/U'
Kanały odbioru	VHF (ZAKRES III) UHF (ZAKRES U) HYPERBAND
Odbiór cyfrowy	Ciągowe zintegrowana nazwiska kablowa satelita telewizji cyfrowej (DVB-T/C) (zgodna z DVB-T2)
Liczba ustawnionych fabrycznych kanałów	1 000
Włącznik kanału	OSD
Wejście anteny RF	75 Ohm (niezbalansowane)
Napięcie robocze	220-240V A.C. 50Hz.
Dźwięk	Niemiecki - Niem. Stereo
Moc wyjściowa audio (WRMS, (10% THD)	2 x 2.5
Zużycie energii (W)	45W
Wymiary telewizora GdDxW (z podstawa)	135 x 554 x 362 (mm)
Wymiary telewizora GdDxW (bez podstawy)	84 x 554 x 336 (mm)
Wyświetla	24"
Temperatura i wilgotność pracy:	0°C do 40°C, 85% maks. rel. wgl.



1. Tryb oczekiwania: Włącza/wyłącza TV
2. Przyciski numeryczne: Włącza kanał, wprowadza liczbę lub literę do pola testowego na ekranie.
3. TV: Przełączka na źródło TV
4. Wyświetle: Calkowite wyświetla dźwięk TV
5. Głosność +/ -
6. Menu: Wyświetla menu TV
7. Przyciski kierunkowe: Pomagają poruszać się po menu, zmieniać listę, zwiększać i zmniejszać poziomu trybu telewizora po naciśnięciu prawa lub lewego przycisku
8. Powtórzenie wyboru użytkownika, wyświetlanie listy kanałów (w trybie telewizora), wyświetla listę kanałów (w trybie TV)
9. Wyświetl/Powrót: Powraca do poprzedniego ekranu, obiera stronę internetową (w trybie telewizora)
10. Przeglądarka mediów: Otwiera ekran przeglądarki mediów
11. Info: Wyświetla informacje o treściach wyświetlanych na ekranie, pozwala ukryć informacje (dostęp - w trybie telewizora)
12. Mój przycisk 1 ("OK")
13. Kolonowy przycisk: Przedstawiający skróty do wyświetlanych na ekranie, aby skorzystać z funkcji kolonowych przycisków
14. Język: Przedstawia języki cyfrowe, gry (dostępny) (telewizja analogowa), wyświetla zmianę audio/język (napisów anagrawa).
15. Napęd: Włącza/wyłącza napasy (gry dostępne)
16. Szybkie przejście do trybu: Przewija klawisz do tyłu w przodzie w mediach takich, jak filmy
17. Brak funkcji
18. Otwarcie/zamknięcie: Otwarcie/zamknięcie wybranych mediów
19. Zatrzymanie/Zatrzymuje otwarcie/zamknięcie mediów
20. Szybkie przejście do przodu: Przewija klawisz do tyłu w mediach takich, jak filmy
21. Pauza: Wyświetla/otwarza dane mediu
22. Ekran: Zmienia aspekt ekranu
23. TeleTest: Wyświetla teletest (gry dostępne), naciśnij ponownie, aby naciąć teletest na obrzeże telewizyjny (min.)
24. Mój przycisk 2 ("OK")
25. PG (Elektroniczny przewodnik po programach): Wyświetla elektroniczny przewodnik po programach specjalne funkcje dla trybów przesyłek nadawcy je przez pięć sekund, gdy TV przełącza się na żądanie z trybu telewizora do trybu ekranu pojawia się komunikat powiadzający wybór. Wybrane MOJ PRZYCISKI zostają skojarzone z wybraną funkcją. Zauważ, że po przeprawieniu Pierwszej instalacji, MOJ PRZYCISKI 1 i 2 powróci do swoich domyślnych funkcji.
26. Wyjście: Zamknie tryb z wybranego menu lub powraca do poprzedniego ekranu
27. Szybkie menu: Wyświetla listę menu dla szynkibiego (min.)
28. Brak funkcji
29. Program +/-
30. Zamiana: Sczytuje przeszukuje pomiędzy poprzednim i następującym kanałem lub zmienia
31. Źródło: Wyświetla wszystkie dostępne audycje i żródła



U włączonych komputerach USB nie ma możliwości połączenia z innymi urządzeniami.

zastąpić inne kable pomiędzy telewizorem a systemem audio (odbiornikiem A/V lub układem głośnikowym).  
Przy aktywnej funkcji ARC telewizor nie wyciąga

automatycznie imnych swoich wtyc. audio. Dialektengi zachodzi koniecznie i rzecznie znamionowania głosności telewizora do zera, jeśli użytkownik chce słyszeć dźwięki z telewizora tylko z głośnika telewizora, a nie z głośników audio. Podczas połączenia urządzenia (tak samo) jak w przypadku innego optycznych czy współosiennych wtyc. audio), jeśli zaznaczy poziomu głośności połączonego urządzenia, należy wybrać klawisz STOP na zdalnym sterowniku. W takim przypadku klawisz STOP zatrzyma położenie głosnosti zostaną przyjor podkowowe kontrolą położenia głosnosti zaznaczonego podczas połączenia urządzenia audio. Podczas połączenia z telewizorem ARC mogą wysiąć pewne sygnały informacyjne o położeniu głosności, niezgodności między telewizorem a połączonym systemem dźwiękowym, względem głosności w stosunku do zakresów głosności.

Zawartość menu TV

System - Zawartość menu Ohraze

Wykonanie																					
Tryb	Tryb obrazu może zostać dopasowany do indywidualnych upodobań. Tryb obrazu może być stawiony w jednej z sześciu opcji: <b>Kino</b> , <b>(rypa)</b> , <b>Sport</b> , <b>Dynamiczny</b> i <b>Naturálny</b> .																				
Kontrast	Dopasowanie wartości jasności i ciemności obrazu.																				
Jaskrawość	Dopasowanie wartości jasności ekranu.																				
Ostrość	Dostępna wartość ostrości dla obiektów wyświetlanych na ekranie.																				
Kolor	Ustawia wartość kolorów, dopasowując je.																				
Oszczędzanie energii	Działanie oszczędzania energii na ekranista, <b>minimum</b> , <b>średnie</b> , <b>maksymalne</b> , <b>auto</b> , <b>oknem</b> lub <b>włączane</b> na wybranej energii.																				
<b>Uwaga:</b> Dostępność opcji może zależeć od wybranego typu.																					
Podświetlenie	To ustawienie kontroluje poziom podświetlenia. Funkcja podświetlenia i <b>degusta wyjazdowa</b> , jest oszczędzaniem energii i jest ustawione na opcję <b>inna niż oszczędzanie</b> .																				
Zawieszane ustawienia	<table border="1"> <tr> <td><b>Kontrast dynamiczny</b></td> <td>Włączenie kontrastu dynamicznego może zwiększać zmianę zgodnie z upodobaniami.</td> </tr> <tr> <td><b>Redukcja szumów</b></td> <td>Jeżeli sygnał jest słaby i występuje zakłócenia obrazu, użyj ustawienia <b>Redukcja Szumów</b>, aby zredukować takie zakłócenia.</td> </tr> <tr> <td><b>Temperatura koloru</b></td> <td>Ustawiająca iżyciąż temperaturę koloru. Dostępne są opcje <b>zimny</b>, <b>normalny</b>, <b>ciepły</b> i <b>osobisty</b>.</td> </tr> <tr> <td><b>Punkt Biali</b></td> <td>Ustawienie to będzie dostępne, jeśli opcja <b>Temperatura Koloru</b> jest ustawiona na osobista. Zwiększa "Ciepło" lub "Zimno" koloru, co wpływa na kolorystykę kolorów.</td> </tr> <tr> <td><b>Zoom Obrazu</b></td> <td>Ustawiający zwiększenie lub zmniejszenie rozmiaru obrazu.</td> </tr> <tr> <td><b>Tryb Film</b></td> <td>Filtrowanie na naprawdę o złożonej teksturze ramki wyświetlającej ramkę na sekundę, która jest adına w trybie normalnym, ułatwiając wybór filmu. Aby skorzystać z tej funkcji, w trakcie oglądania filmu, aby wprowadzić sezceny z szybkimi ruchami.</td> </tr> <tr> <td><b>Odcień skóry</b></td> <td>Pozwala kontrastu może być zmieniony pomiędzy 7-5 a 5.</td> </tr> <tr> <td><b>Zmiana koloru</b></td> <td>Ustawia kolory.</td> </tr> <tr> <td><b>HDMI Pełny Zakres</b></td> <td>Podciąża ogólną jasność HDMI, funkcja ta będzie widoczna. Można użyć lej funkcji, aby porządkować obraz w obramie.</td> </tr> <tr> <td><b>Resetuj</b></td> <td>Resetuje ustawienia obrazu do ustawień fabrycznych (za wyjątkiem trybu <b>trybu ani</b>).</td> </tr> </table>	<b>Kontrast dynamiczny</b>	Włączenie kontrastu dynamicznego może zwiększać zmianę zgodnie z upodobaniami.	<b>Redukcja szumów</b>	Jeżeli sygnał jest słaby i występuje zakłócenia obrazu, użyj ustawienia <b>Redukcja Szumów</b> , aby zredukować takie zakłócenia.	<b>Temperatura koloru</b>	Ustawiająca iżyciąż temperaturę koloru. Dostępne są opcje <b>zimny</b> , <b>normalny</b> , <b>ciepły</b> i <b>osobisty</b> .	<b>Punkt Biali</b>	Ustawienie to będzie dostępne, jeśli opcja <b>Temperatura Koloru</b> jest ustawiona na osobista. Zwiększa "Ciepło" lub "Zimno" koloru, co wpływa na kolorystykę kolorów.	<b>Zoom Obrazu</b>	Ustawiający zwiększenie lub zmniejszenie rozmiaru obrazu.	<b>Tryb Film</b>	Filtrowanie na naprawdę o złożonej teksturze ramki wyświetlającej ramkę na sekundę, która jest adına w trybie normalnym, ułatwiając wybór filmu. Aby skorzystać z tej funkcji, w trakcie oglądania filmu, aby wprowadzić sezceny z szybkimi ruchami.	<b>Odcień skóry</b>	Pozwala kontrastu może być zmieniony pomiędzy 7-5 a 5.	<b>Zmiana koloru</b>	Ustawia kolory.	<b>HDMI Pełny Zakres</b>	Podciąża ogólną jasność HDMI, funkcja ta będzie widoczna. Można użyć lej funkcji, aby porządkować obraz w obramie.	<b>Resetuj</b>	Resetuje ustawienia obrazu do ustawień fabrycznych (za wyjątkiem trybu <b>trybu ani</b> ).
<b>Kontrast dynamiczny</b>	Włączenie kontrastu dynamicznego może zwiększać zmianę zgodnie z upodobaniami.																				
<b>Redukcja szumów</b>	Jeżeli sygnał jest słaby i występuje zakłócenia obrazu, użyj ustawienia <b>Redukcja Szumów</b> , aby zredukować takie zakłócenia.																				
<b>Temperatura koloru</b>	Ustawiająca iżyciąż temperaturę koloru. Dostępne są opcje <b>zimny</b> , <b>normalny</b> , <b>ciepły</b> i <b>osobisty</b> .																				
<b>Punkt Biali</b>	Ustawienie to będzie dostępne, jeśli opcja <b>Temperatura Koloru</b> jest ustawiona na osobista. Zwiększa "Ciepło" lub "Zimno" koloru, co wpływa na kolorystykę kolorów.																				
<b>Zoom Obrazu</b>	Ustawiający zwiększenie lub zmniejszenie rozmiaru obrazu.																				
<b>Tryb Film</b>	Filtrowanie na naprawdę o złożonej teksturze ramki wyświetlającej ramkę na sekundę, która jest adına w trybie normalnym, ułatwiając wybór filmu. Aby skorzystać z tej funkcji, w trakcie oglądania filmu, aby wprowadzić sezceny z szybkimi ruchami.																				
<b>Odcień skóry</b>	Pozwala kontrastu może być zmieniony pomiędzy 7-5 a 5.																				
<b>Zmiana koloru</b>	Ustawia kolory.																				
<b>HDMI Pełny Zakres</b>	Podciąża ogólną jasność HDMI, funkcja ta będzie widoczna. Można użyć lej funkcji, aby porządkować obraz w obramie.																				
<b>Resetuj</b>	Resetuje ustawienia obrazu do ustawień fabrycznych (za wyjątkiem trybu <b>trybu ani</b> ).																				

**PZV** aktywnej funkcji **ABG** telewizor nie wycisza zastępcznych kabli pomiędzy telewizorem a systemem audio (odbiornikiem A/V lub układem głośnikowym).

automatyczności i innych swoich właściwości. Działanie koniecznościowe telewizora polega na zmianie głosowości i selekcji kanałów. W tym przypadku klawiszami sterującymi są przyciski sterujące głosowo, a nie klawisze klawiatury. W celu zmiany głosowości telewizora na żądaną wartość należy naciąć przycisk głosowy, a następnie wybrać głosowość, której chce się skorzystać. Po wybraniu głosowości telewizor automatycznie zmienia głosowość. W celu zmiany kanału należy naciąć przycisk zmiany kanału, a następnie wybrać kanał, który chce się skorzystać. Po wybraniu kanału telewizor automatycznie zmienia kanał. W celu zmiany głosowości telewizora na żądaną wartość należy naciąć przycisk głosowy, a następnie wybrać głosowość, której chce się skorzystać. Po wybraniu głosowości telewizor automatycznie zmienia głosowość. W celu zmiany kanału należy naciąć przycisk zmiany kanału, a następnie wybrać kanał, który chce się skorzystać. Po wybraniu kanału telewizor automatycznie zmienia kanał.

Uwayaya: ARE USUALLY WALKING TEST

<b>Obejmę trybą pełną / losowe</b>	<b>Wyszczególnię wyrazem, że nie jestem zainteresowany / nie chcem podatku.</b>
Rozpoznaję oznakę otwarcia, której nie jestem zainteresowany, i uchomam [E]	Wyszczególnię wyrazem, że nie jestem zainteresowany / nie chcem podatku, kolejnym [E]
Rozpoznaję oznakę, której nie jestem zainteresowany, i uchomam [E]	Plik będzie ochroniany bez pieczęci (gostaszyny)
Rozpoznaję oznakę otwarcia, której nie jestem zainteresowany, i uchomam [E]	Wyszczególnię wyrazem, że nie jestem zainteresowany / nie chcem podatku, kolejnym [E]
Rozpoznaję oznakę otwarcia, której nie jestem zainteresowany, i uchomam [E]	Wyszczególnię wyrazem, że nie jestem zainteresowany / nie chcem podatku, kolejnym [E]
Rozpoznaję oznakę otwarcia, której nie jestem zainteresowany, i uchomam [E]	Wyszczególnię wyrazem, że nie jestem zainteresowany / nie chcem podatku, kolejnym [E]
<b>CEC</b>	<b>Włączcie</b>

**PZV** aktywnej funkcji **ABG** telewizor nie wycisza zastępcznych kabli pomiędzy telewizorem a systemem audio (odbiornikiem A/V lub układem głośnikowym).

automatyczności i innych swoich właściwości. Działanie koniecznościowe telewizora polega na zmianie głosowości i selekcji kanałów. W tym przypadku klawiszami sterującymi są przyciski sterujące głosowo, a nie klawisze klawiatury. W celu zmiany głosowości telewizora na żądaną wartość należy naciąć przycisk głosowy, a następnie wybrać z menu głosową funkcję. Następnie należy naciąć przycisk głosowy, aby zmienić głosowość. W celu zmiany głosowości telewizora na żądaną wartość należy naciąć przycisk głosowy, a następnie wybrać z menu głosową funkcję. Następnie należy naciąć przycisk głosowy, aby zmienić głosowość.

UWADJA: A HISTORICAL PERSPECTIVE ON THE POPULATION OF WEMBLEY

Kontrast	Wartość kontrastu dynamicznego może zostać zmieniona zgodnie z upodobaniami.
Redukcja szumów	Jedzi sygnał jest słabzy i występuje zakłócenia obrazu, użij ustawienia <b>Redukcja Szumów</b> aby zredukować i takie zakłócenia.
Temperatura koloru	Ustawa pożądaną temperaturę koloru. Dostępna są opcje zimny, normalny, ciepły i osobiste.
Punkt Bieli	Ustawienie do biegły, do lepszej, jeśli opcja <b>Temperatura Koloru</b> jest ustalona na osobista, Zwiększy ciepło i uświetni kolory, na przykład piżmawki kolorowe Lewo lub Prawo.
Zonem Obrazu	Ustawa i żądany format ramki obrazu.
Tryb Film	Filmy sa nagrywane z różnych liczb ramek w sekundzie, która jest sama razem z pojemnością nośnika i ogólną jakością filmu. Włącz tą funkcję w trakcie oglądania filmu, aby lepiej widać seanse i szybkiem ruchem.
Odcień skór	Position kontrastu może być zmieniony ponizej/-5 a 5.
Zmiana koloru	Ustawa powiązana z kolorem.
HDMI Pełny Zakres	Podczas oglądania za zdroju HDMI, funkcja ta będzie widoczna. Można użyc tej funkcji, aby porządkować w obrębie.
Resetuj	Resetuje ustawienia obrazu do ustawień fabrycznych (za wyjątkiem trybu <b>on/off</b> ).

System - Zawartość menu ustawień		
Dostęp warunkowy	Kontroluje metodę dostępu do ustawień konfiguracyjnych.	Kontroluje metodę dostępu do ustawień konfiguracyjnych, jeśli są dostępne.
Język	Mózgowiec ustawił tryk (jeżeli w założeniu kontrola rodziców) i wówczas pojawia się hasło. W tym menu można zmienić język.	Aby zmienić język, należy kontroliować kontrolą rodziców.
Kontrola Rodziców	<b>Blokada Klawiszy</b> oraz <b>Ochrona Rodziców</b> . Mózgowiec z "funkcją" ustawić nowy PIN lub zmienić PIN.	<b>Blokada Programów Niedozwolonych dla Dzieci.</b> Mózgowiec z "funkcją" ustawić nowy PIN lub zmienić PIN.
Balans	Ustawienia głośności słuchawkowej.	Ustawienia głośności słuchawkowej.
Słuchawki	Priorytet słuchawek przesyła się upowinie, że dzwiek w słuchawkach jest ustawiony na niskim poziomie, w celu uniknięcia uszczerbeliny słuchu.	Ustawienia głośności słuchawek.
Tryb dzwonek	Możesz wybrać tryb dzwonek jeśli jest to obciążające na ogólnym kanale.	Ustawia timer dysponowania, który wyłącza telewizor po wybranym czasie. Ustawia timer dla wybranych programów.
AV (funkcja automatycznego ograniczania głośności)	Ustawia określony poziom głośności dla programów.	Data/Godzina
Słuchawki/Wyjście audio	Podłączając zewnętrzną wzmacniacz do TV, korzystaj z wyjścia słuchawkowego, możesz wybrać te opcje jako Wyjście. Jeśli podłączysz słuchawki do TV, ustaw te opcje przed użyciem słuchawek, sprawią, że ten element menu jest ustawiony na Słuchawki. Jeśli jest ustawiona na Wyjście, sygnał wyjściowy w gniazdku słuchawkowym będzie usłyszany na maksymum, co może uszkodzić słuch.	Žródła
Basy dynamiczne	Włącza lub wyłącza dynamiczny Bass.	Wyświetlacz
Wyjście cyfrowe	Ustawia tryb audio wyjścia cyfrowego.	Niedosłyszący
		Ustawienia dla osób, które mają problem słyszenia.
		Opis Audio
		Wyświetl informacje o licencji Oprogramowania Open Source.
		Uwaga: Niektóre opcje mogą być niedostępne, zależnie od modelu, tego typu i tego wydania przy pierwszej instalacji.

System - Zawartość menu dźwięku		
Głośność	Ustawianie głośności.	
Korektor	Wybieraj tryb equalizera. Ustawienia indywidualne są dostępne tylko w trybie Użytkownika.	
Balans	Dopuszczanie głośności słuchawkowej.	
Słuchawki	Ustawianie głośności słuchawkowej.	
Tryb dzwonek	Priorytet słuchawek przesyła się upowinie, że dzwiek w słuchawkach jest ustawiony na niskim poziomie, w celu uniknięcia uszczerbeliny słuchu.	
AV (funkcja automatycznego ograniczania głośności)	Ustawia określony poziom głośności dla programów.	
Słuchawki/Wyjście audio	Podłączając zewnętrzną wzmacniacz do TV, korzystaj z wyjścia słuchawkowego, możesz wybrać te opcje jako Wyjście. Jeśli podłączysz słuchawki do TV, ustaw te opcje jako Słuchawki. Przed użyciem słuchawek, sprawią, że ten element menu jest ustawiony na Słuchawki. Jeśli jest ustawiona na Wyjście, sygnał wyjściowy w gniazdku słuchawkowym będzie usłyszany na maksymum, co może uszkodzić słuch.	
Basy dynamiczne	Włącza lub wyłącza dynamiczny Bass.	
Wyjście cyfrowe	Ustawia tryb audio wyjścia cyfrowego.	

jesli ten poziom jest wyłączony, uniemożliwia dostęp do audycji.

**Uwaga:** jeśli opcja kraju przy Pierwszej instalacji jest ustawiona w Francji, Wczytaj (za Austin), wartość kodu programu nieco różni się od tego, ustawionego w 18 i 19 wariantach.

**Blokada klawisz.** Kiedy blokada klawiszów zostanie WŁACZONA, telewizor będzie mógł być sterowany jedynie za pomocą plota. W tym przypadku przyciski kontrolne na TV nie będą działać.

**Ustawianie kodu PIN.** Definiuje nowy numer PIN.

**Domyślny PIN/CICAN:** Opcja ta będzie zaznaczana jeśli moduł CI nie będzie obecny w gniazdzie CI telewizora. Korzystając z tej opcji można zmienić domyślny PIN CI CAN.

**Domyślny PIN:** może być ustawiony na 0000 lub 1234, jeśli określony PIN jest zarezerwowany w zlecaniu wybranego kraju (pozostały w Pierwszej instalacji). Użyj go.

Niektóre opcje mogą być niedostępne, zależnie od wybranego kraju, przy Pierwszej instalacji.

### Elektroniczny przewodnik po programach (EPG)

Niektoare kanały przesyłają informacje na temat ich programu. Niedostępny EPG, aby wyświetlić menu programu telewizyjnego.

Dostępne są 3 tryby wyświetlenia programu: wg godziny, listy, teraz/następny. Aby przełączyć pomiędzy nimi, stosuj się do poleceń znajdujących się na ekranie.

### Program godzinny

Zobacz programy po wiele godzin przedziału czasowym. Wyświetla opcję filtrowania. Wyświetla menu Wybierz typ (przyciski: Napasy). Wyświetla menu wyboru typu audycji. Przy pominie tej funkcji można prześwietkać danej programu po programach zgadź się z wybranym rozdzielczością programu. Informacje dotyczące programów, podświetlone na ekranie, zostaną usunięte.

**Konfiguracja ustawień kontroli rodzicielskiej** Opcje menu Ustawienia Rodzicelskich mogą być ustawione do zablokowania użytkownika oglądania pewnych programów, kanałów lub korzystania z menu. Ustawienia te można odczytać w menu System-Ustawienia>Rodzicelskie.

**Blokada menu:** Ustawienie to zezwala na dostęp lub blokuję dostęp do wszystkich menu lub instancji tego TV.

**Blokada programów niedozwolonych dla dzieci:** Gdy opcja jest aktywna, TV pobiera ze stacji nadawcy informacje o poziomie klasyfikacji, teści programów |

(\*) W tym miejscu wyświetlony będzie pożądany kod podzwrotnym kanałem.

**Poziom. Przedział czasu (czterony przyciski):** Wyświetla programy z poprzedniego wycinka czasu.

**Program lista(\*)**

(\*) W tym miejscu wyświetlony będzie pożądany kod podzwrotnym kanałem.

**Poziom. Przedział czasu (czterony przyciski):** Wyświetla programy z poprzedniego wycinka czasu.

## Działanie ogólnie TV

### Korzystanie z listy kanałów

Tekstowy sortuje wszystkie stacje, zapisane na liście kanałów. Listy kanałów możesz edytować, usuwając ukłonne kanały lub skrywając stacje, przy użyciu opcji Wyświetlanie kanałów.

Funkcja ta może być wyłączona dla przekazu bezpośredniego.

Wyszukuj kanały polecone ze stacjami. Aby je wybrać: Wyszukuj kanały sieciowe odbrane przez antenę, TV, cyfrową kabelową. Wyszukuj kanały sieciowe odbrane przez kabel.

Funkcja może być używana do doborania kanałów analogowych. Dostępne są 2 tryby kanałów analogowych.

Wyszukuj kanały polecone ze stacjami. Aby je wybrać: Wyszukuj kanały sieciowe odbrane przez antenę, TV, cyfrową kabelową. Wyszukuj kanały sieciowe odbrane przez antenę, TV, cyfrową kabelową. Wyszukuj kanały sieciowe odbrane przez kabel.

Funkcja może być używana do doborania kanałów analogowych. Dostępne są 2 tryby kanałów analogowych.

Wyszukuj kanały polecone ze stacjami. Aby je wybrać: Wyszukuj kanały sieciowe odbrane przez antenę, TV, cyfrową kabelową. Wyszukuj kanały sieciowe odbrane przez kabel.

Funkcja może być używana do doborania kanałów analogowych. Dostępne są 2 tryby kanałów analogowych.

Wyszukuj kanały polecone ze stacjami. Aby je wybrać: Wyszukuj kanały sieciowe odbrane przez antenę, TV, cyfrową kabelową. Wyszukuj kanały sieciowe odbrane przez kabel.

Funkcja może być używana do doborania kanałów analogowych. Dostępne są 2 tryby kanałów analogowych.

Wyszukuj kanały polecone ze stacjami. Aby je wybrać: Wyszukuj kanały sieciowe odbrane przez antenę, TV, cyfrową kabelową. Wyszukuj kanały sieciowe odbrane przez kabel.

Funkcja może być używana do doborania kanałów analogowych. Dostępne są 2 tryby kanałów analogowych.

Wyszukuj kanały polecone ze stacjami. Aby je wybrać: Wyszukuj kanały sieciowe odbrane przez antenę, TV, cyfrową kabelową. Wyszukuj kanały sieciowe odbrane przez kabel.

Funkcja może być używana do doborania kanałów analogowych. Dostępne są 2 tryby kanałów analogowych.

Wyszukuj kanały polecone ze stacjami. Aby je wybrać: Wyszukuj kanały sieciowe odbrane przez antenę, TV, cyfrową kabelową. Wyszukuj kanały sieciowe odbrane przez kabel.

Funkcja może być używana do doborania kanałów analogowych. Dostępne są 2 tryby kanałów analogowych.

Wyszukuj kanały polecone ze stacjami. Aby je wybrać: Wyszukuj kanały sieciowe odbrane przez antenę, TV, cyfrową kabelową. Wyszukuj kanały sieciowe odbrane przez kabel.

Funkcja może być używana do doborania kanałów analogowych. Dostępne są 2 tryby kanałów analogowych.



Obsługiwane rozdzielczości DVI

Podłączając UZ zadania do telewizor

zatrudniające się w jednostce organizacyjnej na podstawie przepisów o działalności gospodarczej

માર્ગદરોહિની

	56Hz	60Hz	66Hz	70Hz	72Hz	75Hz
640x400				<input checked="" type="checkbox"/>		
640x480			<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	
800x600	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
936x624						<input checked="" type="checkbox"/>
1024x768		<input checked="" type="checkbox"/>				
1152x864		<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
1152x870		<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
1280x768		<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
1360x768		<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
1280x960		<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
1280x1024		<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
1400x1050		<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
1440x900		<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
1600x1200		<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
1680x1050		<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
1920x1080		<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

Obalniciuvana formantu nlikáuva dla trubu IISB

Obsługiwane formaty plików w użyciu			
Multimedialna	Rozszerzenie	Format	Uwagi
Wideo	.mpg, .mpeg .vob .mp4 .mkv .avi .flv	MPGE1-2 MPGE2 MPGE4_Xvid H.264 MPGE4_VC-1 MPGE4_Xvid H.264 MPGE4_VP8 soerenson	MPEG-1: 768x576 @ 30P MPEG-1: 768x576 @ 30P, MPEG-2: 1920x1080 @ 30P 1920x1080 @ 30P H.264@1080 @ 30P H.264@1080 @ 30P Screenon: 352x288 @ 30P
	.mp4, .mov, .3gp, .3gp, .stremium MPEG-1, ts, tp, .tp, .mkv .3gp		
Dźwięk	.mp3	MPGE4_H.264 MPGE1 Layer 2/3	Layer2: 32 Kbps ~44.1 kHz (przepływność) / 32 kHz, 44.1 kHz, 48 kHz, 16 kHz, 22.05 kHz, 24 kHz (częstotliwość probowania) Layer3: 32 Kbps ~32 Kbps (przepływność) / 32 kHz, 44.1 kHz, 48 kHz, 16 kHz, 22.05 kHz, 24 kHz, 8.0 kHz, 11.025 kHz, 12 kHz (częstotliwość probowania)
		AC3	32Kbps ~ 340Kbps (przepływność) / 32kHz, 44.1 kHz, 48kHz (częstotliwość probowania)
		AAC	16 Kbps ~ 576 Kbps (przepływność) / 48kHz, 44.1 kHz, 32kHz, 24kHz, 22.05 kHz, 16 kHz, 12kHz, 8kHz (częstotliwość probowania)
		EAC3	32 Kbps ~ 6 Kbps (przepływność) / 32kHz, 44.1 kHz, 48 kHz (częstotliwość probowania)
		LPCM	Napodpisany Bitt PCM, Podpisany/Niepodpisany 16bit PCM (big or little endian), 24bit PCM (big endian), DVD LPCM / 16/20/24 bit (przepływność) / 32 kHz, 44.1 kHz, 8 kHz, 11.025 kHz, 16 kHz, 22.05 kHz, 24 kHz, 32 kHz, 44.1 kHz, 48 kHz, 88 kHz, 96 kHz, 176.4 kHz, 192 kHz (częstotliwość probowania)
		IMA-ADPCM/ MS-ADPCM	384Kbps (przepływność) / 8kHz, 48kHz (częstotliwość probowania)
		LBR	32 Kbps ~ 96 Kbps (przepływność) / 32 kHz, 44.1 kHz, 48 kHz (częstotliwość probowania)
Obrzą	.jpg .bmp	Linia haszowa Progresywna -	Rozdzielenie (Sz. x W): 1700x4010000 Rozdzielenie (Sz. x W): 4000x4000 Rozdzielenie (Sz. x W): 5760x4096
Napisy	.sub, .srt	-	-

## Safety Information

- Do not place any heat sources such as electric heaters, radiators, etc. near the TV set.
- Do not place the TV on the floor and inclined surfaces.

To avoid danger of suffocation, keep plastic bags out of the reach of the babies, children and domestic animals.

- Carefully attach the stand to the TV. If the stand is provided with screws, tighten the screws firmly to prevent the TV from tilting. Do not over-tighten the screws and mount the stand rubbers properly.
- Do not dispose of the batteries in fire or with hazardous or flammable materials.

**Warning:** Batteries must not be exposed to excessive heat such as sunshine, fire or the like.

- Avoid danger of electric shock, keep plastic bags out of the reach of the babies, children and domestic animals.

Carefully attach the stand to the TV. If the stand is provided with screws, tighten the screws firmly to prevent the TV from tilting. Do not over-tighten the screws and mount the stand rubbers properly.

- Do not dispose of the batteries in fire or with hazardous or flammable materials.

**Warning:** Batteries must not be exposed to excessive heat such as sunshine, fire or the like.

- Avoid danger of electric shock, keep plastic bags out of the reach of the babies, children and domestic animals.

Carefully attach the stand to the TV. If the stand is provided with screws, tighten the screws firmly to prevent the TV from tilting. Do not over-tighten the screws and mount the stand rubbers properly.

- Do not dispose of the batteries in fire or with hazardous or flammable materials.

**Warning:** Batteries must not be exposed to excessive heat such as sunshine, fire or the like.

- Avoid danger of electric shock, keep plastic bags out of the reach of the babies, children and domestic animals.

Carefully attach the stand to the TV. If the stand is provided with screws, tighten the screws firmly to prevent the TV from tilting. Do not over-tighten the screws and mount the stand rubbers properly.

- Do not dispose of the batteries in fire or with hazardous or flammable materials.

**Warning:** Batteries must not be exposed to excessive heat such as sunshine, fire or the like.

- Avoid danger of electric shock, keep plastic bags out of the reach of the babies, children and domestic animals.

Carefully attach the stand to the TV. If the stand is provided with screws, tighten the screws firmly to prevent the TV from tilting. Do not over-tighten the screws and mount the stand rubbers properly.

- Do not dispose of the batteries in fire or with hazardous or flammable materials.

**Warning:** Batteries must not be exposed to excessive heat such as sunshine, fire or the like.

- Avoid danger of electric shock, keep plastic bags out of the reach of the babies, children and domestic animals.

Carefully attach the stand to the TV. If the stand is provided with screws, tighten the screws firmly to prevent the TV from tilting. Do not over-tighten the screws and mount the stand rubbers properly.

## Contents

Safety Information .....	2
Markings on the Product .....	2
Environmental Information .....	3
Features .....	4
Accessories Included .....	4
Standby Notifications .....	4
TV Control Button & Operation .....	4
Inserting the Batteries into the Remote .....	5
Connect Power .....	5
Antenna Connection .....	5
License Notification .....	5
Specifications .....	6
Remote Control .....	7
Connections .....	8
Switching On/Off .....	9
First Time Installation .....	9
Media Browser Menu .....	10
CEC .....	10
TV Menu/Contents .....	11
General TV Operation .....	15
Using the Channel List .....	15
Configuring Parental Settings .....	15
Electronic Programme Guide (EPG) .....	15
Teletext Services .....	16
Software Upgrade .....	16
Troubleshooting & Tips .....	16
AV and HDMI Signal Compatibility .....	17
Supported File Formats for USB Mode .....	18
Supported DVI Resolutions .....	19



**CAUTION**  
RISK OF ELECTRIC SHOCK  
DO NOT OPEN

CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK DO NOT REMOVE COVER (OR BACK). REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

In extreme weather (storms, lightning) and long inactive period (going on holiday) disconnect the TV set from the mains.

The mains plug is used to disconnect TV set from the mains and therefore it must remain readily operable. If the TV set is not disconnected electrically from the mains, the device will still draw power for all situations even if the TV is in standby mode or switched off.

Note: Follow the on screen instructions for operating the related features.

## IMPORTANT - Please read these instructions fully before installing or operating

**WARNING:** Never let people (including children) with reduced physical, sensory or mental capabilities or lack of experience and/or knowledge use electrical devices unsupervised.

• Use this TV set at an altitude of less than 5000 meters above the sea level, in dry locations and in regions with moderate or tropical climates.

• The TV set is intended for household and similar indoor use but may also be used in public places.

• For ventilation purposes, leave at least 5cm of free space around the TV.

• The ventilation should not be impeded by covering or blocking the ventilation openings with items, such as newspapers, table-cloths, curtains, etc.

• The power cord plug should be easily accessible. Do not place the TV, furniture, etc. on the power cord. A damaged power cord/plug can cause fire or give you an electric shock. Handle the power cord by the plug, do not pull the TV by pulling the power cord. Never touch the power cord/plug with wet hands as this could cause a short circuit or electric shock.

Never make a knot in the power cord or tie it with other cords. When damaged it must be replaced, this should only be done by qualified personnel.

• Do not expose the TV to dripping or splashing of liquids and do not place objects filled with liquids, such as vases, cups, etc. on or over the TV (e.g. on shelves above the unit).

• Do not expose the TV to direct sunlight or do not place open flames such as lit candles on the top of or near the TV.

- Avoid danger of suffocation, keep plastic bags out of the reach of the babies, children and domestic animals.

To avoid danger of suffocation, keep plastic bags out of the reach of the babies, children and domestic animals.

- Carefully attach the stand to the TV. If the stand is provided with screws, tighten the screws firmly to prevent the TV from tilting. Do not over-tighten the screws and mount the stand rubbers properly.

To avoid danger of suffocation, keep plastic bags out of the reach of the babies, children and domestic animals.

- Carefully attach the stand to the TV. If the stand is provided with screws, tighten the screws firmly to prevent the TV from tilting. Do not over-tighten the screws and mount the stand rubbers properly.


To avoid danger of suffocation, keep plastic bags out of the reach of the babies, children and domestic animals.



**CLASS 1 LASER PRODUCT**

**CLASS 1 LASER PRODUCT**

**CLASS 1 LASER PRODUCT**



*Note: The position of the control button may differ depending on the model.*

You TV has a single control button. This button allows you to control the Standby/On / Source / Programme and Volume functions of the TV.

#### Operating with the Control Button

- Remote controlled colour TV
- Fully integrated digital terrestrial/cable/satellite TV (DVB-T/T2C)
- HDMI inputs to connect other devices with HDMI sockets
- USB input
- OSD menu system
- Stereo sound system
- Teletext
- Headphone connection
- Automatic programming system
- Manual tuning
- Automatic power down after up to eight hours.
- Sleep timer
- Child lock
- Automatic sound mute when no transmission.
- NTSC playback
- AVL (Automatic Volume Limiting)
- PLI (Frequency Search)
- Picture of function

#### Accessories included

- Remote Control
- Batteries: 2 x AAA
- Instruction Book
- Power Cord

#### Standby Notifications

If the TV does not receive any input signal (e.g. from an aerial or -HDMI source) for 5 minutes, it will go into standby. When you next switch-on, the following message will be displayed: "TV switched to stand-by mode automatically because there was no signal for a long time." Press OK to continue.

If the TV is on and isn't being operated for a while it will go into standby. When you next switch-on, the following message will be displayed: "TV switched to stand-by mode automatically because no operation was made for a long time." Press OK to continue.

## WALL MOUNTING WARNINGS

- Read the instructions before mounting your TV on the wall.
- The wall mount kit is optional. You can obtain from your local dealer, if not supplied with your TV.
- Do not install the TV on a ceiling or on an inclined wall.
- Use the specified wall mounting screws and other accessories.
- Tighten the wallmounting screws firmly to prevent the TV from fall. Do not over-tighten the screws.

## WARNING

Apparatus connected to the protective earthing of the building installation through the MAINS connection or through other apparatus with a connection to protective earthing – and to a television distribution system using coaxial cable, may in some circumstances create a fire hazard. Connection to a television distribution system has therefore to be provided through a device providing electrical isolation below a certain frequency range (galvanic isolator, see EN 50/728-11)

**Environmental Information**  
This television is designed to be environment friendly. To reduce energy consumption, you can follow these steps:

- If you set the **Energy Saving** to **Minimum, Medium, Maximum** or **Auto** the TV will reduce the energy consumption accordingly. If you like to set the **Backlight** to a fixed value set as **Custom** and adjust the **Backlight** (located under the **Energy Saving** setting) manually using Left or Right buttons on the remote. Set as **Off** to turn its setting off.
- Available **Energy Saving** options may differ depending on the selected **Mode** in the **System>Picture menu**.
- The **Screen Saver** settings can be found in the **System>Picture** menu. Note that some picture settings will be unavailable to be changed!
- If pressed Right button while **Auto** option is selected or Left button while **Custom** option is selected, "Screen will be off in 15 seconds." message will be displayed on the screen. Select **Proceed** and press **OK** to turn the screen off immediately. If you don't press any button, the screen will be off in 15 seconds.

## WARNING

Do not ingest the battery. Chemical Burn Hazard  
This product or the accessories supplied with the product may contain a combination cell battery. If the combination cell battery is swallowed, it can cause severe internal burns in just 2 hours and can lead to death.  
Keep new and used batteries away from children. If the battery compartment does not close securely, stop using the product and keep it away from children.  
Always ensure the television set is not ovenaving the edge of the supporting furniture. Always educate children about the dangers of climbing on furniture to reach the television set or its controls.  
Always route cords and cables connected to your television so they cannot be tripped over, pulled or grabbed.  
NEVER place a television set in an unstable location.  
NEVER place the television set on tall furniture (for example, cupboards or bureaux) without a strong support for the furniture and the television set to a suitable support.  
NEVER place the television set on cloth or other materials that may be located between the television set and supporting furniture.  
NEVER place items that might tempt children to climb, such as toys and remote controls, on the top of the television or furniture on which the television is placed.  
The equipment is only suitable for mounting at heights 52 m.  
If the existing television set is going to be retained and relocated, the same considerations as above should be applied.

## WARNING

A television may fall, causing serious personal injury or death. Many injuries are particularly to children who are able to climb on furniture or fixtures such as: ALWAYS use cabinets or stands or mounting methods recommended by the manufacturer of the television set.  
ALWAYS use furniture that can safely support the television set.  
ALWAYS ensure the television set is not ovenaving the edge of the supporting furniture.  
ALWAYS educate children about the dangers of climbing on furniture to reach the television set or its controls.  
ALWAYS route cords and cables connected to your television so they cannot be tripped over, pulled or grabbed.  
NEVER place a television set in an unstable location.  
NEVER place the television set on tall furniture (for example, cupboards or bureaux) without a strong support for the furniture and the television set to a suitable support.  
NEVER place the television set on cloth or other materials that may be located between the television set and supporting furniture.  
NEVER place items that might tempt children to climb, such as toys and remote controls, on the top of the television or furniture on which the television is placed.  
The equipment is only suitable for mounting at heights 52 m.  
If the existing television set is going to be retained and relocated, the same considerations as above should be applied.

**+ or Programme - option.** Press and hold the button for about 2 seconds to activate the selected option. The icon colour of the option changes when activated. Then press the button to switch to the next or previous channel in the channel list.

**To change source:** Press the control button to display the function options menu and then press the button consecutively to move the focus to **Source** option. Press and hold the button for about 2 seconds to activate this option. The icon colour of the option changes when activated. Then press the button once again to display the sources list. Scroll through available sources by pressing the button. TV will automatically switch to the highlighted source.

**Note:** Main menu OSD cannot be displayed via the control button.

**Operation with the Remote Control**

Press the **Menu** button on your remote control to display main menu. Use the directional pad and **OK** button to navigate and set. Press **Return/Back** button to quit a menu screen.

#### Input Selection

Once you have connected external systems to your TV, you can switch to different input sources. Press the **Source** button on your remote control consecutively to select the different sources.

**Changing Channels and Volume**

You can change the programme and volume +/- buttons by using the **Programme +/-** and **Volume +/-** buttons on the remote.



#### Inserting the Batteries into the Remote

Remove the screw that secures the battery compartment cover on the back side of the remote control first. Lift the cover gently, insert two size **AAA** batteries. Make sure the (+) and (-) signs match (observe correct polarity). Do not mix old and new batteries. Replace only with same or equivalent type. Place the cover back on. Then screw the cover back on again.



**Connect Power**

**IMPORTANT:** The TV set is designed to operate on 220-240V AC, 50 Hz socket. After unpacking, allow the TV set to reach the ambient room temperature before you connect the set to the mains.



#### Products

#### Specification

TV Broadcasting	PAL/BIG DIGITAL/NTSC
Receiving Channels	VHF (BAND III)-UHF (BAND U)-HYPERBAND
Digital Reception	Full integrated digital terrestrial/cable TV (DVB-C/DVB-T2 compliant)
Number of Preset Channels	1,000
Channel Indicator	On Screen Display
RF Aerial Input	75 Ohm (unbalanced)
Operating Voltage	220-240V AC, 50Hz
Audio	German+Niarm Stereo
Audio Output Power (W/RMS.) (10% THD)	2 x 2.5
Power Consumption (W)	45W
TV Dimensions DxDxH (with foot) (mm)	135 x 554 x 362
TV Dimensions DxDxH (without foot) (mm)	84 x 554 x 336
Display	24"
Operation temperature and operation humidity	0°C up to 40°C, 85% humidity max

#### Antenna Connection

Connect the aerial or cable TV plug to the **AERIAL INPUT** (ANT) socket located on the back of the TV.



#### License Notification

The terms **HDMI**, **HDMI High-Definition Multimedia Interface**, and the **HDMI** logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.



©HDMI Thread Group LLC. All Rights Reserved.


Manufactured under license from Dolby Laboratories. Dolby, Dolby Audio, and the double-D symbol are trademarks of Dolby Laboratories Licensing Corporation. The **Ci Plus** Logo is a trademark of Ci Plus LLP.

**Information for Users on Disposal of Old Equipment and Batteries**

**[European Union only]** Equipment bearing these symbols should not be disposed as general household waste. You should look for appropriate recycling facilities and systems for the disposal of these products.

**Notice:** The sign **Pn** below the symbol for batteries indicates that this battery contains lead.

## Remote Control



## Connections

	Connector	Type	Cables	Device
1	HDMI Connection (back/Side)			
2	SIDE AV	Side AV (Audio/Video) Connection (Side)		
3	SPDIF	SPDIF (Coaxial Out) Connection (Side)		
4	HEADPHONE	Headphone Connection (Side)		
5	USB	USB Connection (Side)		
6	C1	C1 Connection (Side)		

See the illustrations on the left side. When using the wall mounting kit (available from a third party in the market), if not supplied, we recommend that you plug all your cables into the back of the CI module before mounting on the wall. Insert or remove the CI module only when the TV is SWITCHED OFF. If CI module is used, (if you block the headphone and Side AV inputs). In this case, I recommend to make the headphones and the Side AV connections before the CI module is inserted. You should refer to the instructions in action manual for details of the settings. The each USB port of the TV supports up to 500mA. Connecting devices that have current value above 500mA may damage your TV. When connecting equipment using a HDMI cable to your TV, you have to use a high shielded (high grade) HDMI cable with ferrites.

If you want to connect a device to the TV, make sure that both the TV and the device are turned off before making any connection. After the connection is done, you can turn on the units and use them.



1. **Standby:** Switches On/Off the TV
2. **Numeric buttons:** Switches the channel, enters a number or a letter in the text box on the screen.
3. **TV:** Switches to TV Source
4. **Mute:** Completely turns off the volume of the TV
5. **Volume +/-:**
6. **Menu:** Displays TV menu
7. **Directional buttons:** Helps navigate menus, content etc. and displays the sub-pages in TXT mode when pressed Right or Left
8. **OK:** Confirms user selections, holds the page (in TXT mode), view channel list (DTV mode)
9. **Back/Return:** Returns to previous screen, opens index page in TXT mode)
10. **Media browser:** Opens the media browsing screen
11. **Info:** Displays information about on-screen content, shows hidden information (reveal - in TXT mode)
12. **My button (1)**
13. **Colourful Buttons:** Follow the on-screen instructions for coloured button functions
14. **Language:** Switches between sound modes (analogue TV displays and changes audio/subtitle language (Digital TV, while available))
15. **Subtitles:** Turns subtitles on and off (where available)
16. **Rapid reverse:** Moves frames backwards in media such as movies
17. **No function**
18. **Play:** Starts to play selected media
19. **Stop:** Stop the media being played
20. **Rapid advance:** Moves frames forward in media such as movies
21. **Pause:** Pauses the media being played
22. **Screen:** Changes the aspect ratio of the screen
23. **Text:** Displays teletext (where available), press again to superimpose the teletext over a normal broadcast picture (mix)
24. **My button 2 (t)**
25. **EPG (Electronic programme guide):** Displays the electronic programme guide
26. **Exit:** Closes and exits from displayed menus or returns to previous screen
27. **Quick Menu:** Displays a list of menus for quick access
28. **No function**
29. **Programme +/-:**
30. **Swap:** Quickly cycles between previous and current channels or sources
31. **Source:** Shows all available broadcast and content sources

## (\*) MY BUTTON 1 & MY BUTTON 2:

These buttons may have a special function depending on the model. However you can set a special function to these buttons by pressing on them for five seconds when on a desired source or channel. A confirmation message will be displayed on the screen. Now the selected MY BUTTON is associated with the selected function.

Note that if you perform **First Time Installation**, MY BUTTON 1&2 will return to their default function.

incompatibilities may occur between the TV and the connected sound system due to the difference of the used volume ranges.  
Note: ARC is supported only via the HDMI2 input.

#### System Audio Control

Allows an Audio Amplifier/Receiver to be used with the TV. The volume can be controlled using the remote control of the TV. To activate this feature set the **Speakers** option in the **System>Settings>More menu** as **Amplifier**. The TV speakers will be muted and the sound of the watched source will be provided from the connected sound system.  
**Note:** The audio device should support System Audio Control feature and CEC option should be set as Enabled.

#### Media Browser Menu

You can play photo, music, and movie files stored on a USB disk by connecting it to your TV. Connect a USB disk to one of the USB inputs located on the side of the TV. Pressing the **Menu** button while in the **Media Browser** mode will access the **Picture**, **Sound** and **Settings** menu options. Pressing the **Menu** button again will exit from this screen. You can set your **Media Browser** preferences by using the **Settings** menu.

#### Loop/Stutter Mode Operation

Start playback with the **Play** button and activate **[E]**. All files in this list will be continuously played in original order.

Start playback with the **OK** button and activate **[E]**. The same file will be displayed continuously (repeat).

Start playback with the **Play** button and activate **[E]**. All files in this list will be played once in random order.

Start playback with the **Play** button and activate **[E]**. All files in this list will be played in random order.

#### CEC

This function allows to control the CEC-enabled devices, that are connected through HDMI ports by using the remote control of the TV.

The **CEC** option in the **System>Settings>More** menu should be set as **Enabled** at first. Press the **Source** button and select the HDMI input of the connected CEC device from the **Sources List** menu. When new CEC source device is connected, it will be listed in source menu with its own name instead of the connected HDMI port's name such as DVD Player, Recorder etc.).

The TV remote is automatically able to perform the main functions after the connected HDMI source has been selected.

To terminate this operation and control the TV via the remote again, press and hold the "0-Zero" button on the remote control for 3 seconds. This feature can also be enabled or disabled under the **System>Settings>More** menu.

The TV supports also **ARC**(Audio Return Channel) feature. This feature is an audio link meant to replace other cables between the TV and the audio system (A/V receiver or speaker system). When **ARC** is active, TV does not emit its other audio outputs automatically. So, you need to decrease TV volume to zero manually, if you want to hear audio from connected audio device only (same as other optical or coaxial digital audio outputs). If you want to change connected device's volume level, you should select that device from the source list. In that case, volume control keys are directed to connected audio device. When using the **ARC** connection, some

Additionally you can set a broadcast type as your favourite one. Priority will be given to the selected broadcast types during the search process and the channels of which will be listed on the top of the **Channel List**. When finished, press **OK** to continue.

You can activate **Store Mode** option at this point. This option will configure your TV's settings for store environment and depending on the TV model being used, the supported features of it may be displayed on the top of the screen as an info banner. This option is intended only for store use. It is recommended to select **Home Only** for home use. This option will be available in **System>Settings>More** menu and can be turned off later.

Press **OK** button on the remote control to continue. After the initial settings are completed TV will start to search for available broadcasts of this selected broadcast types.

After all the available stations are stored, scan results will be displayed. Press **OK** to continue. The **Edit Channel List** menu will be displayed next. You can edit the channel list according to your preferences or press the **Menu** button to quit and watch TV.

While the search continues a message may appear, asking whether you want to sort channels according to the LCN? Select **Yes** and press **OK** to confirm. (**LCN** is the logical Channel/number system that organizes available broadcasts in accordance with a recognizable channel number sequence if available).

**Note:** Note that, some options may not be available depending on the country selection. **Media Playback** via **USB** input.

You can connect 2.5" and 3.5" inch hard disk with external power supply or external hard disk drives or USB memory stick to your TV by using the **USB** inputs of the TV.

**IMPORTANT!** Back up the files on your manufacturer device before connecting them to your TV. Manufacturer device will not be responsible for any file damage or data loss.

Certain types of USB devices (e.g. MP3 players) or USB hard disk drives/memory sticks may not be compatible with this TV. The TV supports FAT32 and NTFS disk formatting.

Wait a little while before each plugging and unplugging as the player may still be reading files. Failure to do so may cause physical damage to the USB player and the TV device itself. Do not pull out your drive while playing a file.

You can use USB hubs with your TV's USB inputs. External power supplied USB hubs are recommended in such a case.

#### Switching On/Off

##### To Switch the TV On

Connect the power cord to a power source such as a wall socket (220-240V AC, 50 Hz).

To switch on the TV from standby mode either:

- Press the **Standby** button, **Programme +/-** or a numeric button on the remote control.
- Press the control button on the TV.

##### To Switch the TV Off

- Press the **Standby** button on the remote control.
- Press the control button on the TV. The function menu will be displayed. The focus will be on the **Standby** option. Press and hold the button for about 2 seconds to activate this option. The icon colour of the option will change. Then press the button once again, the TV will switch into standby mode.

**To power down the TV completely, unplug the power cord from the mains socket.**  
**Note:** When the TV is switched into standby mode, the standby LED will blink to indicate that features such as Standby Mode, Sleep, Over Air Download or timer is active. The LED can also blink when you switch on the TV from standby mode.

#### First Time Installation

When turned on for the first time, the language selection screen is displayed. Select the desired language and press **OK**.

On the next screen, set your preferences using the directional buttons.

**Note:** Depending on the Country selection you may be asked to enter a PIN at this point. The selected PIN cannot be 0000. You have to enter it if you are asked to enter a PIN for any menu operation later.

#### About Selecting Broadcast Type

**Digital Aerial:** If **Digital Aerial** broadcast search option is turned on, the TV will search for digital cable broadcasts after other initial settings are completed.

The TV is turned on, the TV will search for digital cable options by your other preferences, a confirmation message may be displayed before starting to search. Select **YES** and press **OK** to proceed. To cancel operation, select **NO** and press **OK**. You can select **Network** or set values such as **Frequency**, **Network ID** and **Search Step**. When finished, press **OK** button.

**Note:** Searching duration will change depending on the selected **Search Step**.  
**Analogue:** If **Analogue** broadcast search option is turned on, the TV will search for analogue broadcasts after other initial settings are completed.

It is recommended to use the TV's **USB** input(s) directly, if you are going to connect a USB hard disk. **Note:** When viewing image files the **Media Browser** menu can only display 1000 image files stored on the connected USB device.

## TV Menu Contents

System - Picture Menu Contents	
Mode	You can change the picture mode to suit your preference or requirements. Picture mode can be set to one of these options: Cinema, Game(optional), Sports, Dynamic and Natural.
Contrast	Adjusts the light and dark values on the screen.
Brightness	Adjusts the brightness values on the screen.
Sharpness	Sets the sharpness value for the objects displayed on the screen.
Colour	Sets the colour value, adjusting the colors.
Energy Saving	For setting the <b>Energy Saving to Custom, Minimum, Medium, Maximum, Auto, Screen Off or Off</b> . <b>Note:</b> Available options may differ depending on the selected <b>Mode</b> .
Backlight	This setting controls the backlight level. The backlight function will be inactive if the <b>Energy Saving</b> is set to an option other than <b>CUSTOM</b> .
Advanced Settings	
Dynamic Contrast	You can change the dynamic contrast ratio to desired value.
Noise Reduction	If the signal is weak and the picture is noisy, use the <b>Noise Reduction</b> setting to reduce the amount of noise.
Colour Temp	Sets the desired colour temperature value. Cool, Normal, Warm and Custom options are available.
White Point	If the Colour Temp option is set as <b>Custom</b> , this setting will be available. Increases the warmth or coolness of the picture by pressing Left or Right buttons.
Picture Zoom	Sets the desired image size format.
Film Mode	Films are recorded at a different number of frames per second to normal television programmes. Turn this feature on when you are watching films to see the fast motion scenes clearly.
Skin Tone	Skin tone can be changed between -5 and 5.
Colour Shift	Adjust the desired colour tone.
HDMI Full Range	While watching from a HDMI source, this feature will be visible. You can use this feature to enhance blacks in the picture.
Reset	Resets the picture settings to factory default settings (except Game Mode).

## System - Sound Menu Contents

System - Sound Menu Contents	
Volume	Adjusts the volume level.
Equalizer	Selects the equalizer mode. Custom settings can be made only when in <b>User mode</b> .
Balance	Adjusts whether the sound comes from the left or right speaker.
Headphone	Sets headphone volume. Please ensure before using headphones that the headphone volume is set to a low level, to prevent damage to your hearing.
Sound Mode	You can select a sound mode (if the viewed channel supports). You can select a sound mode (if the viewed channel supports).
AVL (Automatic Volume Limiting)	Sets the sound to obtain fixed output level between programmes.
Headphone/Lineout	When you connect an external amplifier to your TV using the headphone jack, you can select this option as <b>Lineout</b> . If you have connected headphones to the TV, set this option as <b>Headphone</b> . Please ensure before using headphones that this menu item is set to <b>Headphone</b> . If it is set to <b>Lineout</b> the output from the headphone socket will be set to maximum which could damage your hearing.
Dynamic Bass	Enables or disables the Dynamic Bass.
Digital Out	Sets digital out audio type.

## System - Settings Menu Contents

Conditional Access	Controls conditional access modules when available.
Language	You may set a different language depending on the broadcaster and the country.
Parental	Enter correct password to change parental settings. You can easily adjust Menulock, <b>Maturity Lock</b> , <b>Child Lock</b> or <b>Guidance</b> in this menu. You can also set a new PIN or change the Default CECAM PIN using the related options. Note: Some menu options may not be available, depending on the country selection in the <b>First Time Installation</b> . Default PIN can be set to 0000 or 1234. If you have deleted a PIN or requested a password on the country selected during the <b>First Time Installation</b> use the PIN that you have defined.
Timers	Sets sleep timer to turn off the TV after a certain time. Sets timer for selected programmes.
Date/time	Sets date and time.
Sources	Enables or disables selected source options.
Accessibility	Accessories accessibility options of the TV.
Hard of Hearing	Enables any special feature sent from the broadcaster.
Audio Description	A narration track will be played for the blind or visually impaired audience. Press OK to see all available Audio Description menu options. This feature is available only if the broadcaster supports it.
More	Displays other setting options of the TV.
Menu Time out	Changes timeout duration for menu screens.
Standby Mode LED	If set to OFF the standby mode LED will not light up when the TV is in standby mode.
Software Upgrade	Ensures that your TV has the latest firmware. Press OK to see the menu options.
Application Version	Displays current software version.
Subtitle Mode	This option is used to select which subtitle mode will be on the screen. (DVB subtitle / Teletext subtitle) Both is available. Default value is DVB subtitle. This feature is available only for the country option of Norway.
Auto TV OFF	Selects the desired time for the TV to automatically go into standby mode when not being operated.
Store Mode	Select this mode for store display purposes. Whilst <b>Store Mode</b> is enabled, some items in the TV menu may not be available.
Power Up Mode	This setting configures the power up mode preference. <b>Last State</b> and <b>Standby Mode</b> options are available.
CEC	With this setting you can enable and disable CEC functionality completely. Press Left or Right button to enable or disable the feature.
CEC Auto Power On	This function allows the connected HDMI-CEC compatible device to turn on the TV and switch to its input source automatically. Press Left or Right button to enable or disable the feature.
Speakers	To hear the TV audio from the connected compatible audio device set as <b>Amplifier</b> . You can use the remote control of the TV to control the volume of the audio device.
OSS	Displays Open Source Software license information.

Note: Some options may not be available depending on the model of your TV as it's features and the selected country in the **First Time Installation**.

## Installation Menu Contents

Automatic channel Scan (Return)	Displays a automatic tuning options. <b>Digital Aerial</b> : Searches and stores aerial DVB stations. <b>Digital Cable</b> : Searches and stores cable DVB stations. <b>Analogue</b> : Searches and stores analogue stations.
Manual Channel Scan	This feature can be used for direct broadcasts only.
Network Channel Scan	Searches for the linked channels in the provided system. <b>Digital Aerial</b> : Searches for aerial network channels. <b>Digital Cable</b> : Searches for cable network channels.
Analogue Fine Tune	You can use this setting for fine tuning a analogue channels. This feature is not available if no analogue channels are stored.
Display Installation settings menu, <b>Standby / Mode Search(N)</b> *, Your TV will search for new or missing channels while in standby. Any new found broadcasts will be stored. <b>Dynamic Channel Updated(*)</b>	
Installation Settings (Optional)	If this option is set and Enabled, the changes on the broadcasts such as frequency, channel name, subtitle language etc., will be applied automatically while watching. (*) Availability depends on provider.
Clear Service List	Use this setting to clear channels stored. This setting is visible only when the <b>Country</b> option is set to Denmark, Sweden, Norway or Finland.
Select Active Network	This setting allows you to select only the broadcasts within the selected network to be listed in the channel list. This feature is available only for the country option of Norway.
Signal Information	You can use this menu item to monitor signal related informations such as signal level/quality/network name etc for available frequencies.
First Time Installation	Deletes all stored channels and settings, resets TV to factory settings.

## General TV Operation

### Using the Channel List

The TV sorts all stored stations in the **Channel List**. You can edit this channel list, set favourites or set active stations to be listed by using the **Channel List** options. Press the **OK** button to open the **Channel List**. You can filter the listed channels by pressing the **Blue** button or open the **Edit Channel List** menu by pressing the **Green** button in order to make advanced changes in the current list.

### Managing the Favourite Lists

You can create four different lists of your favourite channels. Enter the **Channel List** in the main menu or press the **Green** button while the **Channel List** is displayed on the screen in order to open the **Edit Channel List** menu. Then pick the desired channel on the **Yellow** button. Then press the **OK** button to open the **Channel Edit Options** menu and select **Add/Favourite** option. Press the **OK** button again. Set the desired list option to **One**. The selected channels will be added to the list. In order to remove a channel or channels from a favourite list follow the same steps and set the desired list option to **Off**.

You can use the **Filter** function in the **Edit Channel List** menu to filter the channels in the **Channel List** permanently according to your preferences. Using this **Filter** option, you can see one of your four favorite lists to be displayed everytime the **Channel List** is opened. The filtering function in the **Channel List** menu will only filter the currently displayed **Channel List** in order to find a channel and tune in to it. These changes will not remain the next time the **Channel List** is opened if you don't save them. To save the changes on the list press the **Red** button after filtering while the **Channel List** is displayed on the screen.

**Configuring Parental Settings**  
The **Parental Settings** menu options can be used to prohibit users from viewing of certain programmes, channels and using of menus. These settings are located in the **System>Settings>>Parental** menu. To display parental lock menu options, a PIN number should be entered. After coding the correct PIN number, **Parental Settings** menu will be displayed.

**Menu Lock**: This setting enables or disables access to all menus or installation menus of the TV.  
**Maturity Lock**: If this option is set, TV gets the maturity information from the broadcast and if this maturity level is disabled, disables access to the broadcast.  
**Note**: If the country option in the **First Time Installation** is set as France, Italy or Austria, **Maturity Lock**'s value will be set to 18 as default.

**Child Lock**: If this option is set to **ON** the TV can only be controlled by the remote control in this case the control buttons on the TV will not work.  
**Set PIN**: Defines a new PIN number.  
**Default CI CAM PIN**: This option will appear as greyed out if no CI module is inserted into the CI slot of the TV. You can change the default PIN of the CI CAM using this option.

**Note**: Default PIN can be set to 0000 or 1234. If you have defined the PIN's required depending on the country selection during the **First Time Installation** use the PIN that you have defined.  
Some options may not be available depending on the country selection in the **First Time Installation**.

### Electronic Programme Guide (EPG)

Some channels send information about their broadcast schedules. Press the **EPG** button to view the **Programme Guide** menu.  
There are 3 different types of schedule layouts available: **Timeline Schedule**, **List Schedule** and **Now/Next Schedule**. To switch between them follow the instructions on the bottom of the screen.

### Timeline Schedule

**Zoom Yellow button**: Press the **Yellow** button to see events in a wider time interval.

**Filter (Blue button)**: Views filtering options.  
**Highlight Genre (Subtitles button)**: Displays **Highlight Genre** menu. Using this feature, you can search in the programme guide database in accordance with the genre, into available in the programme guide will be searched and results matching your criteria will be highlighted.

**Options (OK button)**: Displays event options.  
**Event Details (Info button)**: Displays detailed information about selected events.

**Next/Prev Day (Programme +/- buttons)**: Displays the events of previous or next day.  
**Search (Text button)**: Displays **Search** menu.  
**Now (Source button)**: Displays current event of the highlighted channel.

### List Scheduler(“)

(*In this regard option, only the events of the highlighted channel will be listed.*)  
**Prev. Time Slice (Red button)**: Displays the events of previous time slice.  
**Next/Prev Day (Programme +/- buttons)**: Displays the events of previous or next day.

**Event Details (Info button)**: Displays detailed information about selected events.  
**Filter (Text button)**: Views filtering options.

**Next Time Slice (Green button)**: Displays the events of next time slice.  
**Options (OK button)**: Displays event options.

### Now/Next Schedule

**Options (OK button)**: Displays event options.

**Event Details (Info button)**: Displays detailed information about selected events.  
**Filter (Blue button)**: Views filtering options.

### Event Options

Use the directional buttons to highlight an event and press the **OK** button to display **Event Options** menu. The following options are available:  
**Select Channel**: Using this option, you can switch to the selected channel.  
**Set Timer on Event / Delete Timer on Event**: After you have selected an event in the EPG menu, press the **OK** button. Selected **Set Timer on Event** option and press the **OK** button. You can set a timer for future events. To cancel an already set timer, highlight that event and press the **OK** button. Then select **Delete Timer on Event**. The timer will be cancelled.

**Note**: Default PIN can be set to 0000 or 1234. If you have defined the PIN's required depending on the country selection during the **First Time Installation** use the PIN that you have defined.

### Teletext Services

Press the **Text** button to enter. Press again to activate page mode, which allows you to see the teletext page and the TV broadcast at the same time. Press once more to exit. It is available, sections in the teletext pages will become colour-coded and can be selected by pressing the coloured buttons. Follow the instructions displayed on the screen.

### Software Upgrade

**Your TV** is capable of finding and updating the firmware automatically via the broadcast signal.

**Software upgrade search via user interface**  
On the main menu select **System>Settings** and then **More**. Navigate to **Software upgrade** and select the **OK** button. In **Upgrade options** menu and select **Scan for upgrade** and press **OK** button to check for a new software upgrade.

If a new upgrade is found, it starts to download the upgrade. After the download is completed confirm the question asking about rebooting the TV by pressing the **OK** to continue with the reboot operation.

### 3 AM search and upgrade mode

**Your TV** will search for new upgrades at 3:00 o'clock if **Automatic scanning** option in the **Upgrade options** menu is set to **Enabled** and if the TV is connected to an aerial signal. If a new software is found and downloaded successfully, it will be installed at the next power on.

**Note**: Do not unplug the power cord while it is booting during the reboot process. If the TV fails to come on after the upgrade, unplug, wait for 2 minutes then plug it back in.

## Troubleshooting & Tips

### Tv will not turn on

Make sure the power cord is plugged in securely to the outlet. Check if batteries are exhausted. Press the Power button on the TV.

### Poor picture

• Check if you have selected the correct TV system.  
• Low signal level can cause picture distortion. Please check antenna access.  
• Check if you have entered the correct channel frequency if you have done manual tuning.  
• The picture quality may degrade when two devices are connected to the TV at the same time. In such a case, disconnect one of the devices.

### No picture

• This means your TV is not receiving any/transmission.  
• Make sure the correct source has been selected.  
• Is the antenna connected properly?  
• Is the antenna cable damaged?  
• Are suitable plugs used to connect the antenna?  
• If you are in doubt, consult your dealer.

### No sound

• Check if the TV is muted. Press the **Mute** button or increase the volume to check.  
• Sound may be coming from only one speaker. Check the balance settings from **Sound** menu.  
• The batteries may be exhausted. Replace the batteries.

### Remote control - no operation

• The batteries may be exhausted. Replace the batteries.  
• Check if the TV is muted. Press the **Mute** button or increase the volume to check.  
• Sound may be coming from only one speaker. Check the balance settings from **Sound** menu.  
• If you cannot select an input source, it is possible that no device is connected. If not,  
• Check the A/V cables and connections if you are trying to switch to the input source dedicated to the connected device.

### Input sources - can not be selected

• If you are trying to switch to the input source dedicated to the connected device.

AV and HDMI Signal Compatibility		
Source	Supported Signals	Available
Side AV	PAL, 50/60	O
	NTSC, 60	O
	480i	60Hz
	480P	60Hz
	576i, 576P	50Hz
HDMI	720P	50Hz, 60Hz
	1080i	50Hz, 60Hz
		O
		24Hz, 25Hz
	1080P	30Hz, 50Hz,
		60Hz

(X: Not Available, O: Available)

In some cases a signal on the TV may not be displayed properly. The problem may be an inconsistency with standards from the source equipment (DVD, Set-top box, etc.). If you do experience such a problem please contact your dealer and also the manufacturer of the source equipment.

#### Supported File Formats for USB Mode


Media	Extension	Format	Notes
Video	.mpg, .mpeg	MPEG 1, 3GP	MPEG 1: 788x576 @ 3GP, MPEG2: 1920x1080 @ 3GP
	.vob	MPEG2	
	.mp4	MPEG4, Xvid, H.264	
	.mkv	H.264, MPEGA, VC-1	1920x1080 @ 3GP
	.avi	MPEG2, MPEGA, Xvid, H.264	
	.flv	H.264/VP6	H.264/VP6: 1920x1080 @ 3GP
	.swf	Sorenson	Sorenson: 360x288 @ 3GP
	.mp4, .mov, .3gp, .3gp,		
	MPEG transport stream, ts, trp, tp, .mkv		
	.3gp	MPEG4, H.264	1920x1080 @ 3GP
Audio	.mp3	MPEG1 Layer 2/3	Layer2: 32Kbps ~ 448Kbps (Bit rate) / 32kHz, 44.1kHz, 48kHz, 16kHz, 22.05kHz ~ 24kHz (Sampling rate)
			Layer3: 32Kbps ~ 320Kbps (Bit rate) / 32kHz, 44.1kHz, 48kHz, 16kHz, 22.05kHz, 24kHz, 8kHz, 11.025kHz, 12kHz (Sampling rate)
		(works only with video files)	32Kbps ~ 320Kbps (Bit rate) / 32kHz, 44.1kHz, 48kHz (Sampling rate)
		AAC	16Kbps ~ 576Kbps (Bit rate) / 48kHz, 44.1kHz, 32kHz, 24kHz, 22.05kHz, 16kHz, 12.8kHz, 11.025kHz, 8kHz (Sampling rate)
		EAC3	32Kbps ~ 8Kbps (Bit rate) / 32kHz, 44.1kHz, 48kHz (Sampling rate)
		LPCM	Unsigned/Bit PCM: Unsigned 16bit PCM (big/little endian), 24bit PCM (big endian), DVD LPCM 16/20/24bit (Bit rate) / 8kHz, 12kHz, 16kHz, 22.05kHz, 24kHz, 32kHz, 44.1kHz, 48kHz, 11.025kHz, 12kHz, 96kHz, 176.4kHz, 192kHz (Sampling rate)
		IMA-ADPCM/MS-ADPCM	384Kbps (Bit rate) / 8kHz ~ 48kHz (Sampling rate)
		LBR	32Kbps ~ 96Kbps (Bit rate) / 32kHz, 44.1kHz, 48kHz (Sampling rate)
Picture	.jpg	Baseline	Resolution(WxH): 17000x1000
		Progressive	Resolution(WxH): 40100x4000
	.bmp	-	Resolution(WxH): 5736x4096
Subtitle	.sub, .srt	-	-

**Supported DVI Resolutions**

When connecting devices to your TV's connectors by using DVI converter cable(DVI to HDMI cable - not supplied), You can refer to the following resolution information.

	56Hz	60Hz	66Hz	70Hz	72Hz	75Hz
640x400				<input checked="" type="checkbox"/>		
640x480		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
800x600	<input checked="" type="checkbox"/>					
832x624						<input checked="" type="checkbox"/>
1024x768		<input checked="" type="checkbox"/>				
1152x864		<input checked="" type="checkbox"/>				
1152x870						<input checked="" type="checkbox"/>
1280x768		<input checked="" type="checkbox"/>				<input checked="" type="checkbox"/>
1360x768		<input checked="" type="checkbox"/>				<input checked="" type="checkbox"/>
1280x860		<input checked="" type="checkbox"/>				<input checked="" type="checkbox"/>
1280x1024		<input checked="" type="checkbox"/>				<input checked="" type="checkbox"/>
1400x1050		<input checked="" type="checkbox"/>				<input checked="" type="checkbox"/>
1440x900		<input checked="" type="checkbox"/>				<input checked="" type="checkbox"/>
1600x1200		<input checked="" type="checkbox"/>				<input checked="" type="checkbox"/>
1680x1050		<input checked="" type="checkbox"/>				<input checked="" type="checkbox"/>
1920x1080		<input checked="" type="checkbox"/>				<input checked="" type="checkbox"/>

VESA WALL MOUNT MEASUREMENTS			
B	Hole Pattern Sizes (mm)	W	H
		75	75
Screw Sizes			
D	Length (X)	min. (mm)	5
		max. (mm)	8
E	Thread (Y)	M4	



	A	B	C	D	E
English	VESA WALL MOUNT MEASUREMENTS	Hole Pattern Sizes (mm)	Screw Sizes	Length (X)	Thread (Y)
Deutsch	MASSANGABEN FÜR VESA-WANDMONTAGE	Lochmustergrößen (mm)	Schraubengrößen	Länge (X)	Gewinde (Y)
Français	DIMENSIONS DU SUPPORT DE FIXATION MURALE VESA	Dimensions des modèles de trous de montage (mm)	Dimensions des vis	Longueur (X)	Filiage (Y)
Italiano	Misurazioni installazione a parete VESA	Dimensioni schema foro (mm)	Dimensioni vite	Lunghezza (X)	Filletatura (Y)
Português	MEDIDAS DE MONTAGEM MURAL VESA	Dimensões do molde de furação (mm)	Tamancos do parafuso	Comprimento (X)	Rosca (Y)
Español	MEASURADAS DEL MONTAJE DE PARED VESA	Tamaños de patrón para agujero (mm)	Tamaños de tornillo	Longitud (X)	Rosca (Y)
Türkçe	VESA DUVARA MONTAJI APARATI ÖLÇÜLERİ	Açılıacak Delik Ölçüleri (mm)	Vida Ölçüleri	Uzunluk (X)	Yüzey (Y)
Ελληνική	ΔΙΑΣΤΑΣΕΙΣ ΒΑΣΗΣ ΤΟΙΧΟΥ VESA	Μεγέθη συμμετόχων οπών (mm)	Μεγέθη βασιών (mm)	Μήκος (X)	Σπεριφύτια (Y)
Polski	WYMIARY DO MONTAŻU NAŚCIENNEGO VESA	Rozmiary szablonu otworów (mm)	Rozmiary wkrętów	Długość (X)	Gwint (Y)
česká	ROZMĚRY DRŽÁKA NA ZEĎ VESA	Rozměry velikosti dír (mm)	Rozměry šroubů	Délka (X)	Závit (Y)
Magyar	VESA FALI TARTÓ MÉRETEK	Lyukak méretének nagysága(mm)	Csavar méret	Hossz (X)	Menet (Y)
Română	MĂSURĂTORI SUPORT PERETE VESA	Dimensiuni tipar gaură (mm)	Dimensiuni suruburi	Lungime (X)	Filet (Y)
Svenska	VESA VÄGGMONTERINGSMÄTT	Hålmönsterstollear (mm)	Skruvstoltek	Längd (X)	Träd (Y)
Nederlands	VESA WANDMONTAGE METINGEN	Grootte booropening (mm)	Schroefgrootte	Lengte (X)	Draad (Y)
Suomi	VESA-SEINAASENNUKSEN MITAT	Reikäkuvion koot (mm)	Ruuvinkoot	Pituus (x)	Kierre (Y)
Norsk	VEGA VÆGGMONTERINGSMÅL	Hullmønster størelser (mm)	Skruestørrelser	Lengde (x)	Tråd (Y)
Dansk	VESA VÆGGMONTERINGS-MÅL	Hulmønster-størelser (mm)	Skruestørrelser	Længde(X)	Tråd (Y)
Русский	РАЗМЕРЫ НАСТЕННОГО КРЕПЛЕНИЯ VESA	Размеры системы отверстий	Размеры винтов	Длина(Х)	Резьба (Y)
беларуская	ПАМЕРЫ НАСЦЕННАГА МАЦАВАННЯ VESA	Памеры сістэмы адтулін	Памеры віントу	Даўжыня (X)	Разьба (Y)
македонски	МЕРКИ ЗА МОНТИРАЊЕ НА СИД ЗА „ВЕСА“	Шема на големини на дупката (мм)	Големина на шрафот	Должина (X)	Наој (Y)
українська	РОЗМІРИ НАСТІННОГО КРИПЛЕННЯ VESA	Відстань між кріпильними отворами, мм	Розміри винтів	Довжина (X)	Діаметр різби (Y)
Srpski	DIMENZIJE VESA ZIDNOG NOSAČA	Dimenzije šablon za bušenje	Dimenzije zatvrtljiva	Dužina (X)	Navoj (Y)
Slovenčina	ROZMERY DRŽÁKA NA STENU VESA	Rozmery veľkostí dier (mm)	Rozmery skrutiek	Dĺžka (X)	Závit (Y)
Slovenščina	mere stenskega nosilca vesa	Velikosti vzorca luknenj (mm)	Velikosti vijakov	Dolžina (X)	Navoj (Y)
Hrvatski	VESA MIJERE ZIDNOG DRŽAČA	Veličine uzorka otvora (mm)	Veličine vijke	Dužina (X)	Navoj (Y)
Bosanski	DIMENZIJE VESA ZIDNOG NOSAČA	Dimenzije šablon za bušenje	Dimenzije vijaka	Dužina (X)	Navoj (Y)
Български	РАЗМЕРИ ЗА КОМПЛЕКТ ЗА МОНТАЖ НА СТЕНА VESA	Размери на отвора (mm)	Размер на болта	Дължинат (X)	Резба (Y)
Lietuvių	VESA TVIRINTIMO PRIE SIEJOS MATAVIMAI	Angos šablonio dydis (mm)	Varžtų dydis	Ilgis (X)	Sriegis (Y)
Latviešu	VESES SIENAS STIPRINĀJUMA IZMĒRI	Caurumu šablonu izmērs (mm)	Skruļu izmēri	Garums (X)	Vītnē (Y)
Eesti	VESA SEINALE KINNITAMISE MÖÖDUD	Kruvi suuruse mõõt (mm)	Kruvi suurus	Kõrgus(x)	Keere (Y)
Shqip	PËRMASAT E NIËSISË SË MONTIMIT NE MUR VESA	Madhësitë modele të vrimate (mm)	Madhësitë e vidhave	Gjatësia (X)	Filitimi (Y)
عربي	مقاييس VESA لتنبيث على الجدار	أحجام التقبب (مم)	الطول (X) الارتفاع (Y)	الارتفاع (Y)	الارتفاع (Y)
עברית	מידות חותם הרכבה על הקיר VESA סטנדרט 75x75 מ"מ	מודל הבניה החומר (מ"מ)	גובה (X) רוחב (Y)	גובה (Y)	רוחב (Y)
فارسی	اندازه های اکتوی سوارخ (متر مربع) VESA	اندازه های اکتوی سوارخ (متر مربع)	طول (X) عرضه (Y)	عرضه (Y)	طول (X)

- TR:** İşbu belgede; VESTEL Elektronik Sanayi ve Ticaret A.Ş., telsiz ekipmanı tipi TFT IDTV 'nin 2014/53/AB sayılı direktifte uygun olduğuunu beyan eder. AB uygunluk beyanının tam metni internet adresinde mevcuttur: doc.vosshub.com
- EN:** Hereby, VESTEL Elektronik Sanayi ve Ticaret A.Ş., declares that the radio equipment type TFT IDTV is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: doc.vosshub.com
- BG:** С настоящото VESTEL Elektronik Sanayi ve Ticaret A.Ş., декларира, че този тип радиооборудование TFT IDTV е в съответствие с Директива 2014/53/EU. Цялостният текст на ЕС декларацията за съответствие може да се намери на следния интернет адрес: doc.vosshub.com
- CZ:** Tímto VESTEL Elektronik Sanayi ve Ticaret A.Ş., prohlašuje, že typ rádiového zařízení TFT IDTV je v souladu se směrnicí 2014/53/EU. Úplné znění EU prohlášení o shodě je k dispozici na této internetové adrese: doc.vosshub.com
- DA:** Hermed erklærer VESTEL Elektronik Sanayi ve Ticaret A.Ş., at radioudstyrstypen TFT IDTV er i overensstemmelse med direktiv 2014/53/EU. EU-overensstemmelseserklæringens fulde tekst kan findes på følgende internetadresse: doc.vosshub.com
- DE:** Hiermit erklärt VESTEL Elektronik Sanayi ve Ticaret A.Ş., dass der Funkanlagentyp TFT IDTV der Richtlinie 2014/53/EU entspricht. Der vollständige Text der EU-Konformitätserklärung ist unter der folgenden Internetadresse verfügbar: doc.vosshub.com
- EL:** Με την παρούσα ο/η VESTEL Elektronik Sanayi ve Ticaret A.Ş., δηλώνει ότι ο ραδιοεπιλογές TFT IDTV πληροί την οδηγία 2014/53/ΕΕ. Το πλήρες κείμενο της δήλωσης συμμόρφωσης ΕΕ διατίθεται στην ακόλουθη ιστοσελίδα στο διαδίκτυο: doc.vosshub.com
- ES:** Por la presente, VESTEL Elektronik Sanayi ve Ticaret A.Ş., declara que el tipo de equipo radioeléctrico TFT IDTV es conforme con la Directiva 2014/53/UE. El texto completo de la declaración UE de conformidad está disponible en la dirección Internet siguiente: doc.vosshub.com
- ET:** Käesolevaga deklareerib VESTEL Elektronik Sanayi ve Ticaret A.Ş., et käesolev raadioseadme tüüp TFT IDTV vastab direktiivi 2014/53/EL nõuetele. ELI vastavusdeklaratsiooni täielik tekst on kättesaadav järgmisel internetaadressil: doc.vosshub.com
- FI:** VESTEL Elektronik Sanayi ve Ticaret A.Ş., vakuuttaa, että radiolaitetyyppi TFT IDTV on direktiivin 2014/53/EU mukainen. EU-vaatimustenmukaisuusvakuutuksen täysimittainen teksti on saatavilla seuraavassa internetsoitteessa: doc.vosshub.com
- FR:** Le soussigné, VESTEL Elektronik Sanayi ve Ticaret A.Ş., déclare que l'équipement radioélectrique du type TFT IDTV est conforme à la directive 2014/53/UE. Le texte complet de la déclaration UE de conformité est disponible à l'adresse internet suivante: doc.vosshub.com
- HR:** VESTEL Elektronik Sanayi ve Ticaret A.Ş., ovime izjavljuje da je radikalna oprema tipa TFT IDTV u skladu s Direktivom 2014/53/EU. Cjeloviti tekst EU izjave o sukladnosti dostupan je na sljedećoj internetskoj adresi: doc.vosshub.com
- HU:** VESTEL Elektronik Sanayi ve Ticaret A.Ş., igazolja, hogy a TFT IDTV típusú rádióberendezés megfelel a 2014/53/EU irányelvnek. Az EU-megfelelőségi nyilatkozat teljes szövege elérhető a következő internethoz címen: doc.vosshub.com
- IT:** Il fabbricante, VESTEL Elektronik Sanayi ve Ticaret A.Ş., dichiara che il tipo di apparecchiatura radio TFT IDTV è conforme alla direttiva 2014/53/UE. Il testo completo della dichiarazione di conformità UE è disponibile al seguente indirizzo Internet: doc.vosshub.com
- LT:** Aš, VESTEL Elektronik Sanayi ve Ticaret A.Ş., patvirtinu, kad radio įrenginių tipas TFT IDTV atitinka Direktyvą 2014/53/ES. Visas ES atitikties deklaracijos tekstas prieinamas šiuo internetu adresu: doc.vosshub.com
- LV:** Ar šo VESTEL Elektronik Sanayi ve Ticaret A.Ş., deklarē, ka radioiekārtai TFT IDTV atbilst Direktīvai 2014/53/ES. Pilns ES atbilstības deklarācijas teksts ir pieejams šādā interneta vietnē: doc.vosshub.com
- MT:** B'dan, VESTEL Elektronik Sanayi ve Ticaret A.Ş., niddikjara li dan it-tip ta' tagħmir tar-radju TFT IDTV huwa konformi mad-Direttiva 2014/53/UE. It-test kollu tad-dikkarazzjoni ta' konformità tal-UE huwa disponibbli f'dan l-indirizz tal-Internet li ġej: doc.vosshub.com
- NL:** Hierbij verklaar ik, VESTEL Elektronik Sanayi ve Ticaret A.Ş., dat het type radioapparatuur TFT IDTV conform is met Richtlijn 2014/53/EU. De volledige tekst van de EU-conformiteitsverklaring kan worden geraadpleegd op het volgende internetadres: doc.vosshub.com
- PL:** VESTEL Elektronik Sanayi ve Ticaret A.Ş., niniejszym oświadczyc, że typ urządzenia radioowego TFT IDTV jest zgodny z dyrektywą 2014/53/UE. Pełny tekst deklaracji zgodności UE jest dostępny pod następującym adresem internetowym: doc.vosshub.com
- PT:** O(a) abaixo assinado(a) VESTEL Elektronik Sanayi ve Ticaret A.Ş., declara que o presente tipo de equipamento de rádio TFT IDTV está em conformidade com a Diretiva 2014/53/UE. O texto integral da declaração de conformidade está disponível no seguinte endereço de Internet: doc.vosshub.com
- RO:** Prin prezenta, VESTEL Elektronik Sanayi ve Ticaret A.Ş., declară că tipul de echipamente radio TFT IDTV este în conformitate cu Directiva 2014/53/UE. Textul integral al declarării UE de conformitate este disponibil la următoarea adresă internet: doc.vosshub.com
- SK:** VESTEL Elektronik Sanayi ve Ticaret A.Ş., týmto vyhlásuje, že rádiové zariadenie typu TFT IDTV je v súlade so smernicou 2014/53/EU. Úplné EU vyhlásenie o zhode je k dispozícii na tejto internetovej adrese: doc.vosshub.com
- SL:** VESTEL Elektronik Sanayi ve Ticaret A.Ş., potrjuje, da je tip radijske opreme TFT IDTV skladen z Direktivo 2014/53/EU. Celotno besedilo izjave EU o skladnosti je na voljo na naslednjem spletnem naslovu: doc.vosshub.com
- SV:** Härmär försäkrar VESTEL Elektronik Sanayi ve Ticaret A.Ş., att denna typ av radioutrustning TFT IDTV överensstämmer med direktiv 2014/53/EU. Den fullständiga texten till EU-försäkran om överensstämmelse finns på följande webbadress: doc.vosshub.com







**TELEFUNKEN**



50696584