



5. Play music wireless



6. Play music wired



?

- Frequently asked questions
- Domande frequenti
- Preguntas frecuentes
- Veelgestelde vragen
- Foire aux questions
- Häufig gestellte Fragen

www.trust.com/19275/faq

© 14-08-2014 Trust International B.V. All rights reserved.

Trust



Wireless Speaker

Jukebar | powerful sound | rechargeable battery

1. Speaker

The diagram shows the top of the speaker with three buttons: a minus sign for volume down, a central button with a speaker icon, and a plus sign for volume up. To the right, a USB-A to USB-C cable is shown, with the USB-C end connected to the speaker's charging port.

2. Charging

This diagram illustrates the charging process. A USB-A to USB-C cable is connected to the speaker's charging port and a laptop. A power adapter is also shown connected to the speaker's charging port. A red light is shown above the USB port on the speaker. A battery icon with a 4H timer indicates the charging duration.

3. Wireless setup 1/2

The diagram shows the speaker with a blue light emanating from the bottom. Above it, a control panel is shown with four buttons: AUX OUT, AUX IN, USB, and ON/OFF. An arrow points to the ON/OFF button. A blue light icon is labeled "In pairing mode".

4. Wireless setup 2/2

This diagram shows the steps for wireless setup on a smartphone. Step 1: Open the Settings app. Step 2: Go to Bluetooth. Step 3: Tap "Trust SPK-02". Below this, a "Wireless troubleshooter" section shows a "no devices found" message, followed by a 4-second button press and a "Trust SPK-02" prompt.