


## 5. Installation - Windows XP

1  13:57  
1x

2 **Open Volume Control**  
**Adjust Audio Properties**  
12:32 PM  
1x

3 **Sounds and Audio Devices Properties**  
Volume Sounds Audio **Voice** Hardware  
Realtek AC97 Audio  
Device volume  
Low High  
 Mute  
 Place volume icon in the taskbar  
Advanced...  
Speaker settings  
Use the settings below to change individual speaker volume and other settings.  
Speaker Volume... Advanced...  
OK Cancel Apply

4 **Sounds and Audio Devices Properties**  
Volume Sounds Audio **Voice** Hardware  
These settings control volume and advanced options for the voice playback or recording device you selected.  
Voice playback  
Default device: Realtek AC97 Audio  
Volume... Advanced...  
Voice recording  
Default device: Realtek AC97 Audio  
**Volume...** Advanced...  
Test hardware...  
OK Cancel Apply

## 6. Installation - Windows XP

5 **Recording Control**  
Options Help  
CD Player Line In Microphone  
Balance: Volume: **Advanced**  
Realtek AC97 Audio

6 **Advanced Controls for Mic Volume**  
These settings can be used to make fine adjustments to your audio.  
Tone Controls  
These settings control how the tone of your audio sounds.  
Bass: Low High  
Treble: Low High  
Other Controls  
These settings make other changes to how your audio sounds. See your hardware documentation for details.  
 **1 Microphone Boost** **Close**

## FAQ

### Frequently asked questions


[www.trust.com/19850/faq](http://www.trust.com/19850/faq)



Please contact technical support for free converter cable  
<http://www.trust.com/contact/support>


© 15-01-2014 Trust International B.V. All rights reserved.

**Trust**




Quick Installation Guide  
Talkee mini microphone


# 1. Microphone



# 2. Installation



# 3. Installation - Windows 8



# 4. Installation - Windows 8 / 7 / Vista

