



**ULTRADESK®**

**SPACE**


**XXL**




**ASSEMBLY INSTRUCTIONS**  
**ANLEITUNG**  
**INSTRUKCJA**




**1** x 6




**2** x 8




**3** x 18




**4** x 8



**5** x 4




**P1** x 2




**P2** x 2




**P3** x 2




**P4** x 1




**P5** x 1




**P6** x 1



**P7** x 1




**P8** x 2




**P9** x 1




**P10** x 1




**P11** x 2




**P12** x 2




**P13** x 2



**P14** x 4




**P15** x 1



**P16** x 1





**P17** x 1




**P18** x 1




**P19** x 4




1.




2.




# 3.




# 4.




**5.**




**6.**




# 7.




# 8.



# 9.



# 10.



# 11.

Press the button for 2-3 seconds to switch on/switch off, lightly press it once, the light color will be changed.  
Drücke die Taste für 2-3 Sekunden, um die Beleuchtung ein- oder auszuschalten, drücke die Taste kurz, um die Farbe der Beleuchtung zu wechseln.  
Wciskaj przycisk przez 2-3 sekundy, aby włączyć lub wyłączyć podświetlenie, wciśnij przycisk krótko, aby zmienić kolor podświetlenia.

