



EN
PL
DE
ES
CZ
SK
RO
HU
BG
RU

Thor¹⁵⁰

QUICK INSTALLATION GUIDE
GAMING KEYBOARD

FEATURES

- Anti-ghosting for 19 keys
- 7-zones RGB backlight with ability to set 11 different modes
- hybrid mechanical switches
- Multimedia function keys

INSTALLATION

- Connect your device to the USB port of your computer
- System will install driver automatically, for first time usage wait around 15 seconds until drivers will be installed
- The device is ready for use

ARROW FUNCTION CHANGE

Press FN + W to swap arrow function with W, A, S, D keys function.

SPEED OF BACKLIGHT EFFECTS

To change the speed of backlight effects press keys FN + Arrow Left/Right

Note: This function not working in modes FN + 2 and FN + 9.

CUSTOM MODE

Custom mode allows you to set the individual illumination of each zone:

1. Hold FN button and double press button 9 to enter into "Custom Mode"
2. Press the FN + arrow Up/Down to change color
3. Press the FN + arrow Right/Left to move between 7 zones
4. Hold FN button and double press button 9 to save settings

PACKAGE CONTENT

- Thor 150 gaming keyboard
- Quick installation guide

SAFETY INFORMATION

- Use as directed.
- Non-authorized repairs or taking the device to pieces make the warranty void and may cause the product damage.
- Avoid to hit or friction with a hard object, otherwise it will lead to grind surface or other hardware damage.
- Do not use the product in low and high temperatures, in strong magnetic fields and in the damp or dusty atmosphere.
- Do not drop, knock, or shake the device. Rough handling can break it.
- Slots and openings in the case are provided for ventilation and should not be obscure. Blocking the vents can cause overheating of the device.

SPECIFICATION

- Keyboard size 448 x 155 x 42 mm
- Connector USB
- Number of key 104
- Number of multimedia keys 12

BACKLIGHT BRIGHTNESS

To change the backlight brightness level press keys FN + Arrow Up/Down.

Note: This function works only in mode FN + 2.

BACKLIGHT COLOR CHANGE

To change the backlight color, press keys FN + Insert

Note: This function works only in mode FN + 2, FN + 6 and FN + 7.

BACKLIGHT MODE CHANGE

Press the keys FN + Scroll Lock, or FN + 0-9 to change between 11 backlight modes.

REQUIREMENTS

- PC or PC compatible device with a USB port
- Windows® XP/Vista/7/8/10, Android, Linux

WARRANTY

- 2 years limited manufacturer warranty

GENERAL

- The safe product, conforming to the EU requirements.
- The product is made in accordance with RoHS European standard.
- The WEEE symbol (the crossed-out wheeled bin) using indicates that this product is not home waste. Appropriate waste management aids in avoiding consequences which are harmful for people and environment and result from dangerous materials used in the device, as well as improper storage and processing. Segregated household waste collection aids recycle materials and components of which the device was made. In order to get detailed information about recycling this product please contact your retailer or a local authority.

EN

PL

DE

ES

CZ

SK

RO

HU

BG

RU

