

SONY

Wireless Stereo Headset Casque stéréo sans fil

Operating Instructions
Mode d'emploi
Manual de instrucciones
使用説明書
사용 설명서
Инструкция по эксплуатации
تعليمات التشغيل
Bedienungsanleitung
Istruzioni per l'uso

Gebruiksaanwijzing
Instruções de operação
Betjeningsvejledning
Käyttöohjeet
Bruksanvisning
Bruksanvisning
Instrukcja obsługi
Kezelési útmutató
Νάvod k použití

Νάvod na obsluhu
Инструкция за експлоатация
Instrucțiuni de utilizare
Navodila za uporabo
Upute za uporabu
Uputstva za korišćenje
Οδηγίες λειτουργίας
Інструкції з експлуатації

WF-C500

Model, Modèle, Modelo, 型號: YY2952

©2021 Sony Corporation
Printed in Vietnam / Imprimé en Vietnam
5-030-787-11(1)



* 5 0 3 0 7 8 7 1 1 * (1)

1

1. Place the headset in the charging case. Close the case. Connect the case to a USB-C charging cable. The case will charge the headset for approximately 3 hours.

2

2. Insert the earbuds into your ear canals. The earbuds are labeled 'M' (medium) and 'SS' (small). The ear canals are labeled 'LL' (left) and 'RR' (right).

3

3. Download the Sony Headphones Connect app from the app store. Open the app and tap the headset icon. The app will show "Bluetooth pairing" and "Bluetooth connected".

4

4. Use the headset to listen to music. Tap the earbud to play/pause music. Double-tap to skip forward. Triple-tap to skip back. Use touch gestures to adjust volume.



